



**ISO Parts Inc.
Stocking Distributors for Military and Aviation Parts**

1300 Pinetree Drive, Unit 9, Indian Harbour Beach, FL, 32937, USA
Tel: +1-321-773-5710 Fax: +1-321-777-0499 Email: sales@iso-parts.com
Web: <http://www.iso-parts.com>

ISO Parts - 2004 Bell Helicopter Inventory Catalog

In Stock and Ready to Ship



Bell Helicopter
A Textron Company

Sorted By Part Number

Part Number	NSN	Description	Quantity	Condition
598	3110-00-100-1651		1	NS
598	5950-00-936-0510	TRANSFORMER,POWER	2	NS
602	4920-01-449-8294	FIXTURE,AIRCRAFT MAINTENANCE	1	AR
2467	6640-01-467-7589	CENTRIFUGE,LABORATORY	1	NS
2490	5330-00-921-3894	SEAL,PLAIN ENCASED	2	NS
4237	5340-01-057-1588	CYLINDER ASSEMBLY,ACTUATING,LINEAR	50	NS
5493			1	NS
07310	2825-00-972-8880	RING,PISTON	3	NS
21650	5826-00-677-6046	MOUNTING	1	NS
27700	6610-01-194-8659	INDICATOR,ATTITUDE	1	SV
38052			1	NS
38613	4920-00-865-8007	ADAPTER,POWER ASSY	1	NS
38613	4920-00-865-8007	ADAPTER,POWER ASSY	1	NS
44000	6515-01-473-8678	CASE,DRUG,MAIN,SUPP	1	AR
52400	3110-00-100-3621		1	NS
60912	5330-00-292-7376		6	NS
75168	3020-00-088-8872	GEAR SET,SPUR,MATCHED	17	NS
75168	3020-00-088-8872	GEAR SET,SPUR,MATCHED	36	NS
75168	3020-00-088-8872	GEAR SET,SPUR,MATCHED	23	NS
77970	5305-00-781-6548	SCREW,ADJUSTING	40	NS
86325	4820-00-688-9658	VALVE	1	NS
99143	5815-00-125-5104	PAD,FELT	1	NS
100348	5306-00-851-5630	BOLT,EYE	2	NS
102550	6610-00-912-3613	INDICATOR,ATTITUDE	1	RP
129060	6610-01-155-8315	INDICATOR,VERTICAL SITUATION	1	RP
133643			5	SV
133646	1650-00-525-2570	RACK,INPUT,CONTROL	1	NS
137287			1	NS
177097	5310-00-595-5811	WASHER,FLAT	219	NS
177097	5310-00-595-5811	WASHER,FLAT	700	NS
229418	5305-01-334-1801	SCREW	1	NS
270310	6515-01-192-6539	TUBE,SUCTION,SURGICAL	1	NS
300081	5340-00-794-2674	CAP,PROTECTIVE,DUST AND MOISTURE SEAL	1	NS
304092			14	NS
323931	5940-00-686-7371	FERRULE,METALLIC SHIELDED CABLE,GROUNDING	1	NS
345280	3110-00-498-6978	BEARING,BALL,ANNULAR	4	NS
536508	5330-00-887-6163	PACKING,PREFORMED	2	NS
600115			4	NS
617908	6615-00-531-2501	GYROSCOPE,DISPLACEMENT	1	AR
653278	5996-00-487-4769	AMPLIFIER,ELECTRONIC CONTROL	1	AR
653278	5996-00-487-4769	AMPLIFIER,ELECTRONIC CONTROL	1	AR
694189	3110-01-127-3560	BEARING	17	NS
761704			22	OH
816202	3110-00-886-1560	BEARING,BALL,DUPLEX	14	NS
1532119	5340-00-860-3653	COVER,ACCESS	1	NS
1544525	5940-00-435-4830	TERMINAL BOARD	1	NS
3007147			1	NS
3012675	5310-01-168-9000		37	NS
3019906			1	RP
4036690	2840-00-280-0011	NOZZLE ASSEMBLY,TURBINE,AIRCRAFT GAS TURB	2	AR
5001311			70	SV
5006086			3	NS
6798023	4920-00-945-8914	ADAPTER,SUPPORT,TUR	4	AR
6848524	2840-00-923-4377	VANE ASSEMBLY,STATOR,TURBINE ENGINE	540	NS
6848524	2840-00-923-4377	VANE ASSEMBLY,STATOR,TURBINE ENGINE	33	NS
6848542	2840-00-923-4377	VANE ASSEMBLY,STATOR,TURBINE ENGINE	50	NS
6848542	2840-00-923-4377	VANE ASSEMBLY,STATOR,TURBINE ENGINE	113	NS
6848542	2840-00-923-4377	VANE ASSEMBLY,STATOR,TURBINE ENGINE	104	NS
6850746	5306-00-924-5889	BOLT,INTERNAL WRENCHING	63	NS
6853279	2840-00-614-2516	WHEEL,TURBINE	1	OH
6871534	4730-00-622-3670	CHIP DETECTOR FITTI	4	NS
6876667	2840-01-239-8439	DISCHARGE TUBE,COMP	21	NS
6876775	3040-01-040-1042	ACCUMULATOR,PNEUMATIC	1	SV
6890917			1	NS

6894363	3020-01-127-2278	GEAR,FUEL PUMP DRIVE		NS
6895929	3020-01-122-0284	PINION,REGENERATOR	1	NS
7581244	2915-01-164-3915	BOWL ASSY,LUBE PUM	2	NS
7583740			1	NS
8351487	3110-00-894-9549	BEARING,ROLLER,CYLINDRICAL	7	NS
8351487	3110-00-894-9549	BEARING,ROLLER,CYLINDRICAL	9	NS
8518495			8	NS
8531750	2935-00-737-6605	COOLER,LUBRICATING OIL,ENGINE	1	NS
8531750	2935-00-737-6605	COOLER,LUBRICATING OIL,ENGINE	1	AR
8535061	2935-00-821-8752	VALVETHERMOSTATIC	1	NS
8603310	3110-00-629-4112	RETAINER AND ROLLERS,BEARING	5	NS
9171473	1620-00-659-7129	INSERT	1510	NS
9525016	1630-00-980-9495	KEY,DISK DRIVE	36	NS
10886953	5340-00-994-1000	COVER,ACCESS	2	NS
11830922	1019-01-071-0715	LOGIC CONTROL,UNIT ASSEMBLY	1	AR
16605993			2	NS
23030962	2840-01-212-1279	SHAFT,TURBINE,NONAIRCRAFT GAS TURBINE ENG	4	NS
23037426	2840-00-923-4377	VANE ASSEMBLY,STATOR,TURBINE ENGINE	32	NS
23037426	2840-00-923-4377	VANE ASSEMBLY,STATOR,TURBINE ENGINE	40	NS
23037426	2840-00-923-4377	VANE ASSEMBLY,STATOR,TURBINE ENGINE	60	NS
23037426	2840-00-923-4377	VANE ASSEMBLY,STATOR,TURBINE ENGINE	108	NS
23052375	2840-01-212-1279	SHAFT,TURBINE,NONAIRCRAFT GAS TURBINE ENG	14	NS
23052375	2840-01-212-1279	SHAFT,TURBINE,NONAIRCRAFT GAS TURBINE ENG	32	NS
23052375	2840-01-212-1279	SHAFT,TURBINE,NONAIRCRAFT GAS TURBINE ENG	24	NS
23052375	2840-01-212-1279	SHAFT,TURBINE,NONAIRCRAFT GAS TURBINE ENG	23	NS
23052375	2840-01-212-1279	SHAFT,TURBINE,NONAIRCRAFT GAS TURBINE ENG	26	NS
41000515	1650-00-402-4932	PISTON,LINEAR ACTUATING CYLINDER	3	SV
41000863	1650-00-071-8751	CAP MOUNTING	1	NS
41006783			1	AR
108026201	5950-00-914-4105	COIL,RADIO FREQUENCY	20	NS
653155316			1	NS
2060621011	1560-00-126-9161	LEG,ENGINE MOUNT,FO	1	NS
6223202001	6615-01-357-7532	CONTROL BOX,DIRECTIONAL,AUTOMATIC PILOT	1	AR
10003512512	5315-00-132-1481	PIN,STRAIGHT,HEADLESS	5	NS
19220001000	5930-00-649-8151	PUSH BUTTON	15	NS
20406063125	1560-00-991-8541	SUMP ASSEMBLY,FUEL	7	NS
7.02E+12			1	NS
610E100	1560-00-789-4969	PUMP,FUEL EJECTOR	1	NS
?	5305-00-806-9717	SCREW,MACHINE	19	NS
?			7	NS
?			2	NS
?	1680-00-021-5510	PANEL,FAULT-FUNCTION INDICATOR,AIRCRAFT	1	NS
?			4	AR
00044 REV A	5330-00-795-1315	SEAL,PLAIN ENCASED	2	NS
001333676 5310			58	NS
002259101 5306			72	NS
0053-1D4A	5340-01-317-9590	CLIP,SPRING TENSION	6	NS
0101383-01	1680-00-780-2121	REEL ASSY,INERTIA L	1	NS
0101383-01	1680-00-780-2121	REEL ASSY,INERTIA L	2	NS
010138301-015870145-3	1680-01-188-8270		1	NS
0101389-09	1680-00-013-1279	CONTROL,INERTIAL REEL	1	NS
0101989-05			6	AR
015-870-145-7	1680-00-780-2121	REEL ASSY,INERTIA L	4	NS
025227-300607			1	NS
02-591-137-0			6	NS
02W10116	1650-00-772-7714	FILTER,FLUID	6	SV
02W10116	1650-00-772-7714	FILTER,FLUID	1	AR
02W10116	1615-00-772-7714	FILTER,FLUID	4	NS
033614-02	2915-01-227-6154	BOWL,FILTER,FUEL	2	NS
047-140-216-001			8	NS
047-140-252-005			2	NS
047-620-019-001			2	NS
047-641-101-001	5340-00-503-1896	BOOT,DUST AND MOISTURE SEAL	1	NS
047-645-232-003			1	NS
048757-25	2915-01-108-3652	FILTER,FLUID	1	NS
050-1780-03			2	NS

100-050B437	5340-00-413-0079	PLUG,PROTECTIVE,DUST AND MOISTURE SEAL	4	NS
100585-7	1285-00-073-2299	COUPLER	4	AR
100621-1	1650-00-944-4436	CAP,LINEAR ACTUATING CYLINDER	3	NS
1-010-086-01	2995-00-777-8541		3	NS
1-010-173-02 REV C	5330-00-455-9704	GASKET	4	NS
1-010-186-01	2945-00-917-7076	GASKET	2	NS
1-010-380-05	2945-00-442-2539	FILTER BODY,INTAKE AIR CLEANER	1	NS
10124F	5962-00-588-8334	MICROCIRCUIT,DIGITAL	1	NS
101-524092-1			3	NS
102-0001-01	6610-00-150-6408	INDICATOR,ATTITUDE	2	SV
1-020-017-01	5331-00-766-8653	O-RING	4	NS
102KS	3110-00-814-7639	BEARING,BALL,ANNULAR	2	NS
1-030-129-01	5310-00-846-1658	NUT,PLAIN,SLOTTED,HEXAGON	50	NS
1-030-141-02	2840-00-739-6923	RETAINER,BOLT,SUN G	2	NS
1-030-192-03			1	NS
1-030-192-06C	3040-00-865-8080	GEARSHAFT,HELICAL	1	NS
1-030-193-01			1	NS
1-030-212-01	5365-00-916-2424	SPACER,RING	7	SV
1-030-214-01			2	NS
1-030-390-05			1	NS
1-030-400-01	2840-00-915-5933	SUPPORT,OIL TRANSFER	1	NS
103100A1	2915-01-005-9196	GOVERNOR,OVERSPEED	2	OH
10-3537004	2925-00-064-9435	EXITER,IGNITION	1	NS
104207-1	1680-00-758-3660	HANDLE,DOOR	1	NS
10450-31327	6610-01-091-3702	ALTIMETER,PRESSURE	2	AR
1048-Z			10	OH
105-14101-3			2	NS
105-450371			1	NS
105-450511-07			1	NS
105589-01	2590-21-913-6028	COVER,VEHICULAR COMPONENTS	1	AR
105-60551-092			1	NS
105-6212-1A			2	NS
105-84112 10B			2	NS
105-84129-A			1	NS
105-911-151			1	SV
105-941201			1	NS
106000A1	2915-01-162-9543	FUEL CONTROL,MAIN,TURBINE ENGINE	2	NS
1-060-030-01	2840-00-012-3283	VANE,INLET GUIDE	40	NS
1-060-126-01	5365-00-017-2675		9	NS
1-060-260-07	2840-00-957-2536		3	NS
1-060-270-05	5365-01-237-6949	PLUG,MACHINE THREAD	1	NS
1-070-101-01	2840-00-876-8754	GEAR,DRIVEN,ACCESSO	1	RP
1-070-102-01	5365-00-833-6692	TEST SET SUBASSEMBLY,ELECTRICAL AND ELECT	1	SV
1-070-103-01	2840-00-475-6951		1	SV
1-070-210-01	2840-00-915-5958		1	NS
1-080-025-01	5330-00-656-8534	GASKET	13	NS
1-080-032-01	3130-00-656-8545		4	NE
1-080-284-01P	5307-00-475-9621	STUD,RECESSED AND STEPPED	8	NS
1-080-350-04	2840-00-766-8633	SHAFT ASSEMBLY,SHOULDERED	16	NS
108-358-020-2	4720-00-915-5880	HOSE ASSEMBLY,METALLIC	1	NS
109762-3-1	4820-01-246-1349	VALVE,SURGE	1	NS
1-100-078-07	2840-00-176-3745	COMPRESSOR ROTOR,CENTRIFUGAL,TURBINE ENI	1	RP
1-100-132-06	2840-01-029-8740	BLADE,TURBINE,ROTOR TURBINE ENGINE	3	NS
1-100-226-08	5365-00-665-7776		2	SV
1-100-227-01	5365-00-655-7768	SPACER,RING	7	SV
1-100-227-02	5365-00-655-7782	SPACER,RING	3	SV
1-100-227-02	5365-00-655-7782	SPACER,RING	13	NS
1-100-227-03	5365-00-665-7781		3	SV
1-100-227-04	5365-00-655-7780	SPACER,RING	2	SV
1-100-227-05	5365-00-655-7779	SPACER,RING	7	SV
1-100-227-06	5365-00-655-7778	SPACER,RING	2	SV
1-100-227-07	5365-00-655-7777	SPACER,RING	1	SV
1-100-227-09	5365-00-655-7791	SPACER,RING	2	SV
1-100-227-10	5365-00-655-7790	SPACER,RING	2	SV
1-100-227-11	5365-00-655-7789	SPACER,RING	10	SV
1-100-227-12	5365-00-655-7788	SPACER,RING	2	SV

1-100-227-14	5365-00-655-7784	SPACER,RING	2	SV
1-100-227-15	5365-00-655-7767	SPACER,RING	1	SV
1-100-227-17	5365-00-655-7783	SPACER,RING	2	SV
1-100-227-18	5365-00-655-7769	SPACER,RING	1	SV
1-100-227-19	5365-00-655-7786	SPACER,RING	1	SV
1-100-227-21	5365-00-655-7766	SPACER,RING	2	SV
1-100-227-24	5365-00-771-7185	SPACER,RING	2	SV
1-100-227-31	5365-00-987-9533	SPACER,RING	2	SV
1-100-227-32	5365-00-989-2830	SPACER,RING	2	SV
1-100-241-13	2840-00-992-4617	BLADE SET,COMPRESSOR ROTOR,TURBINE ENGIN	4	NS
1-100-241-13A	2840-00-992-4617	BLADE SET,COMPRESSOR ROTOR,TURBINE ENGIN	2	NS
1-100-286-09H	2840-00-176-3782	BLADE,COMPRESSOR ROTOR,TURBINE ENGINE	10	NS
1-100-289-01	5365-00-949-5495		9	SV
1-100-289-02	5365-00-948-8032		5	SV
1-100-294-03			1	NS
110-034-1	9390-00-923-6007	NONMETALLIC SPECIAL SHAPED SECTION	1	NS
1-100-361-05	2840-00-176-3788	BLADE SET,COMPRESSOR,AIRCRAFT GAS TURBINE	1	NS
1-100-383-02	2840-00-839-6778	BLADE SET,COMPRESSOR ROTOR,TURBINE ENGIN	4	NS
1-100-383-04	2840-00-176-3773	BLADE SET,COMPRESSOR,AIRCRAFT GAS TURBINE	66	NS
1-100-383-04	2840-00-176-3773	BLADE SET,COMPRESSOR,AIRCRAFT GAS TURBINE	52	NS
1-100-384-04	2840-00-176-3758	BLADE SET,COMPRESSOR,AIRCRAFT GAS TURBINE	1	NS
1-100-384-04A	2840-00-176-3758	BLADE SET,COMPRESSOR,AIRCRAFT GAS TURBINE	8	NS
1-100-384-04A	2840-00-176-3758	BLADE SET,COMPRESSOR,AIRCRAFT GAS TURBINE	1	NS
1-100-384-05	2840-00-176-3791	BLADE,COMPRESSOR ROTOR,TURBINE ENGINE	8	NS
1-100-385-02	2840-00-839-6780	BLADE SET,COMPRESSOR ROTOR,TURBINE ENGIN	9	NS
1-100-385-04	2840-00-176-3789	BLADE SET,COMPRESSOR,AIRCRAFT GAS TURBINE	13	NS
1-100-411-04	5365-00-003-1165	RING,EXTERNALLY THREADED	2	NS
1-100-454-09			1	NS
110-046-5	5905-00-431-3115	RESISTOR,VARIABLE,WIRE WOUND,NONPRECISION	8	NS
1-100-505-02	5340-00-181-1225	PLATE,MENDING	18	NS
110-071-1	9320-00-113-5845	RUBBER STRIP	50	NS
1-101-080-06	2840-01-100-7609	SHAFT ASSY,FRONT	1	NS
1-101-090-07	2925-01-466-0892	ROTOR ASSEMBLY	1	AR
1-101-110-07			1	NS
11052502-1	1430-00-779-0720		28	NS
1107460-03				NS
1-110-134-01	5310-00-133-1251	NUT,SLEEVE	1	NS
1-110-141-02	5365-00-437-4013	RING,EXTERNALLY THREADED	6	NS
1-110-151-01	5305-00-995-6914	SCREW,CAP,SOCKET HEAD	79	NS
1-110-161-03	5365-00-053-1676		1	SV
1-110-181-06C	3110-00-774-8304		2	NS
1-110-194-04	5330-00-731-5456		1	SV
1-110-316-03	2840-00-736-3984		1	NS
1-110-321-01	5365-00-893-2733	SHIM	5	NS
1-110-334-04A			1	NE
1-110-470-13	2840-01-008-5734	HOUSING,ANTIFRICTION BEARING,AIRCRAFT GAS T	1	NS
1-110-470-13	2840-01-008-5734	HOUSING,ANTIFRICTION BEARING,AIRCRAFT GAS T	1	NS
1-110-500-03	2840-00-957-6580		1	NS
1-110-520-19	2840-00-570-9803	NOZZLE,TURBINE,AIRCRAFT GAS TURBINE ENGINE	1	NS
1-110-520-21	2840-00-087-6851	NOZZLE,TURBINE,AIRCRAFT GAS TURBINE ENGINE	1	NS
1-120-000-14	2840-00-176-3579	NOZZLE,TURBINE,AIRCRAFT GAS TURBINE ENGINE	2	NS
1-120-000-14	2840-00-176-3579	NOZZLE,TURBINE,AIRCRAFT GAS TURBINE ENGINE	2	AR
1-120-000-14	2840-00-176-3579	NOZZLE,TURBINE,AIRCRAFT GAS TURBINE ENGINE	6	NS
1-120-000-14	2840-00-176-3579	NOZZLE,TURBINE,AIRCRAFT GAS TURBINE ENGINE	2	NS
1-120-000-6	2530-00-034-8616	COMPRESSOR,BRAKE	1	NS
112-131-553-1B2			1	SV
112-303-1			2	NS
112KS400			30	NS
1-130-001-02	5310-00-654-8930	NUT,PLAIN,ROUND	227	NS
1-130-003-01	5365-00-670-4342	PLUG,MACHINE THREAD	2	SV
1-130-094-05	5330-00-950-6860	SEAL,VAPORIZER,COMB	10	NS
1-130-097-03	2840-00-950-6850	SPACER,SEAL,VAPORIZ	37	NS
1-130-112-01			67	NS
1-130-112-01	2915-00-976-9307		25	NS
1-130-123-02			6	NS
1-130-176-01			122	NS

1-130-235-01	5310-00-945-5750	WASHER,KEY	12	NS
1-130-590-02			1	NS
1-130-720-02	2995-00-949-8219	MANIFOLD,FLUID,AIRCRAFT	3	NS
1-140-025-05	2840-00-925-4148		3	NS
1-140-029-02	5340-00-778-2272	LOCKING PLATE,NUT AND BOLT	22	NS
1-140-029-02	5340-00-778-2272	LOCKING PLATE,NUT AND BOLT	200	NS
1-140-056-10	2840-00-876-8716	CYLINDER,POWER,TURB	3	NS
1-140-061-01	5310-00-658-5308		1	NS
1-140-062-01	2840-00-587-7089	CUP,LOCK,BEARING RETAINING NUT	8	NS
1-140-062-01	2840-00-587-7089	CUP,LOCK,BEARING RETAINING NUT	1	NS
1-140-063-03			1	AR
1-140-182-01	2840-00-945-8225		2	NS
1-140-189-02	2840-00-925-4149		1	NS
1-140-191-02			1	NE
1-140-192-02			9	NS
1-140-192-02	1560-00-925-4150		1	NS
1-140-210-16B			1	NS
1-140-212-09	5365-00-929-8443	RING,EXTERNALLY THREADED	1	SV
1-140-222-02			116	SV
1-140-225-01	2840-00-778-2274	LOCKWIRE,SECOND TUR	14	NS
1-140-233-02	5365-00-156-8958	RING,EXTERNALLY THREADED	6	NS
1-140-242-01	5305-00-842-2430	SCREW,MACHINE	200	NS
1-140-244-01	5306-00-897-5278	BOLT,MACHINE	44	NS
1-140-245-01			400	NS
1-140-271-01	2840-00-924-7767	TUBE,OIL TRANSFER	4	NS
1-140-273-03	2840-00-925-4151	BLADE,TURBINE,ROTOR TURBINE ENGINE	31	SV
1-140-274-02	2835-00-943-2216	BLADE,TURBINE ROTOR,NONAIRCRAFT GAS TURBI	31	SV
1-140-274-03			1	NS
1-140-420-04	2840-00-085-3880	NOZZLE,TURBINE,AIRCRAFT GAS TURBINE ENGINE	1	NS
114CS103-4	3110-00-096-0895		2	NS
114L234-1	3120-00-817-9888		8	NS
114P5003-107			1	NS
114P5003-108			1	NS
114P5003-17			2	NS
114P5003-31			2	NS
114P5003-39			1	NS
114P5003-40			1	NS
114P5003-45			1	NS
114P5003-61			1	NS
114P5003-65			6	NS
114P5003-79			1	NS
114P5003-80			1	NS
114P5003-83			2	NS
114P5003-913			1	NS
114P5003-93	1560-00-012-8747	PANEL ASSEMBLY,UPPER	1	NS
114P5003-94	1560-00-012-8743	PANEL ASSEMBLY,LOWER	1	NS
1-150-002-01	2840-00-656-8526	ADAPTER,OIL STRAINER HOUSING,POWER TURBIN	39	NS
1-150-031-02	5310-00-484-0973	WASHER,KEY	116	NS
1-150-044-02	5310-00-619-5368	NUT,PLAIN,HEXAGON	118	NS
1-150-108-01	2840-00-942-7073		8	NS
1-150-126-01			70	NS
1-150-240-06	2840-01-009-3366	DIFFUSER,EXHAUST	1	NS
1-150-260-02	2840-00-943-2411		2	NS
1-150-280-05	2840-00-925-9986	SUPPORT ASSEMBLY,DI	17	NS
1-160-040-03	2840-00-994-4302	HOUSING ASSY,TEMPER	4	NS
1-160-043-01	2840-00-430-7912	ADAPTER,BLEED AIR	1	SV
1-160-047-02	5330-01-501-4480	GASKET	20	NS
1-160-135-01	5342-00-656-8549	BRACKET,CLAMP	9	NS
1-160-254-01			2	NS
1-160-299-02	5330-00-984-7138	GASKET	17	NS
1-160-299-02	5330-00-984-7138	GASKET	40	NS
1-160-317-01	4730-00-958-8194	BOLT,FLUID PASSAGE	5	NS
1-160-318-01	4730-00-278-5817	CONNECTOR,MULTIPLE,FLUID PRESSURE LINE	5	NS
1-160-325-01	5340-00-064-9432	LOCKING PLATE,NUT AND BOLT	55	NS
1-160-362-03	5330-00-179-4207	GASKET	8	NS
1-160-421-01			2	NS

1-160-454-01			2	NS
1-160-468-01	5340-00-775-6514	BRACKET,ANGLE	5	NS
1-160-500-04			1	NS
1-160-622-01	5342-00-957-2392		4	NS
1-160-629-01	5365-00-136-7511	SHIM	35	NS
1-160-629-02	5330-00-078-9933	GASKET	11	NS
1-16-850-16			1	NS
1-170-050-04D	2840-00-976-9301		2	NS
1-170-240-60	2915-01-005-9197	FUEL CONTROL,MAIN,TURBINE ENGINE	2	NS
1-170-240-60	2915-01-005-9197	FUEL CONTROL,MAIN,TURBINE ENGINE	1	OH
1-170-500-01	4710-00-134-0063	TUBE ASSEMBLY,METAL	2	NS
1-180-103-03			2	NS
1-180-190-03	2840-00-782-1771	VALVE,LINEAR,DIRECTIONAL CONTROL	1	RP
1-190-004-5	2840-00-106-2356	VANE,TURBINE NOZZLE,TURBINE ENGINE	393	NS
1-190-009-05H			1	NS
1-190-009-05H	2840-00-925-9560		1	NS
1-190-010-03	2840-01-010-5949		1	NS
1-190-015-02	2840-00-106-2360	FLANGE,TURBINE NOZZLE SEAL RING	22	NS
1-190-019-02			40	NS
1-190-037-01			4	NS
1-190-050-06	2840-01-009-3722	NOZZLE,TURBINE,AIRCRAFT GAS TURBINE ENGINE	2	NS
1-190-050-06	2840-01-009-3722	NOZZLE,TURBINE,AIRCRAFT GAS TURBINE ENGINE	1	NS
1-190-050-07	2840-01-089-4291	NOZZLE,TURBINE,TURBINE ENGINE	1	NS
1-190-050-07	2840-01-089-4291	NOZZLE,TURBINE,TURBINE ENGINE	1	NS
120-004C54-45	5365-00-937-4483	SHIM	1	NS
120-006360-45	5365-00-120-1176	SHIM	2	NS
120-006C15-0	5365-00-134-3373	SHIM	12	NS
120-006C60-45	5365-00-120-1176	SHIM	4	NS
120-006C677-71			4	NS
120-007-C38-25	5365-00-420-2100	SHIM	12	NS
120-007C67-3			8	NS
120-059-1	5365-00-222-0388	SHIM	7	NS
120-064-6H	5305-01-064-3606	SCREW,SHOULDER	1	NS
120-064-6H	5305-01-064-3606	SCREW,SHOULDER	19	NS
12-288-8	4820-01-189-8686	CUP,LEATHER,VALVE	2	NS
12315-0027-0002	1680-00-023-2058	BLADE,WINDSHIELD WIPER	2	NS
1-300-047-01			5	NS
1-300-142-02	4720-00-966-2204	HOSE ASSEMBLY,NONMETALLIC	1	NS
1-300-143-02	4720-00-966-2230	HOSE ASSEMBLY,NONMETALLIC	40	NS
1-300-143-02	4720-00-966-2230	HOSE ASSEMBLY,NONMETALLIC	96	NS
1-300-174-01	5330-00-054-3592	SEAL,PLAIN ENCASED	1	NS
1-300-192-01	2915-00-981-3078	NOZZLE ASSEMBLY,STA	2	NS
1-300-193-01	2915-00-991-9145	INJECTOR,FUEL METER	20	NS
1-300-194-04	4810-00-068-6712	VALVE,SOLENOID	2	NS
1-300-216-02	5330-00-072-9704	SEAL,PLAIN ENCASED	1	NS
1-300-232-02	5330-00-893-0347	SEAL,PLAIN ENCASED	2	AR
1-300-235-02	5330-00-179-1224	SEAL,PLAIN ENCASED	1	NE
1-300-243-02	4730-00-786-2992	CHIP DETECTOR,MAGNETIC	1	NS
1-300-245-02	2925-00-064-9435	EXITER,IGNITION	3	NS
1-300-245-02J	2925-00-064-9435	EXITER,IGNITION	9	NS
1-300-254-02	2915-00-954-4237	STRAINER ELEMENT,SEDIMENT	1	NS
1-300-266-01	5340-00-515-9196	RETAINER,NUT AND BOLT	33	NS
1-300-348-01	2925-00-957-9947	IGNITER,SPARK,GAS TURBINE ENGINE	3	NS
1-300-355-01	5330-00-946-4877	RETAINER,PACKING	8	NS
1-300-361-02	2915-00-964-2273	FILTER ASSEMBLY,REL	2	NS
1-300-362-01	2915-00-959-6282	FILTER ASSEMBLY,VALVE	1	NS
1-300-369-01	5330-00-828-8060	O-RING	7	NS
134HM10078-1	2945-00-736-3978	FILTERING DISK,FLUID	2	NS
13600LA 902A1	3110-01-051-1016	CONE AND ROLLERS,TAPERED ROLLER BEARING	8	NS
138093-01-01	6610-00-866-5509	INDICATOR,ATTITUDE	2	RP
141-10450-045	1680-00-759-8274	PANEL,FAULT-FUNCTION INDICATOR,AIRCRAFT	1	NS
14602-1JF1	6610-00-663-8800	INDICATOR,ATTITUDE	5	OH
147B31	6685-00-557-0370	INDICATOR,TEMPERATURE,ELECTRICAL RESISTAN	1	OH
148110-01-01	6610-00-419-3154	INDICATOR,ATTITUDE	1	SV
148-700-01-01	6610-00-179-9035	INDICATOR,ATTITUDE	4	RP
1487-00-01-01	6610-00-179-9035	INDICATOR,ATTITUDE	3	NS

148700-03-01	6610-01-023-6073	INDICATOR,ATTITUDE	1	SV
150SG1009-5	5977-01-255-6392	BRUSH,ELECTRICAL CONTACT	4	NS
1560 UH1 653			1	AR
1560-UH1-653			1	AR
156673-12-0154	4720-00-148-8602	HOSE ASSEMBLY,NONMETALLIC	1	NS
156673-12-0154	4720-00-148-8602	HOSE ASSEMBLY,NONMETALLIC	2	NS
156UH1455001			12	NS
158-001-1	2935-00-543-7296	COOLER,LUBRICATING OIL,ENGINE	2	RP
15819-11	3110-00-068-0079	BEARING,BALL,ANNULAR	4	NS
159-34201-10			12	OH
159-34201-30	1620-00-314-5702	DAMPER,SHIMMY	1	NS
159-34201-30	1620-00-314-5702	DAMPER,SHIMMY	1	OH
1616160-1	3110-00-949-0596	BEARING,BALL,ANNULAR	26	NS
164A168-1	2915-00-017-9021	PUMP,SUBMERGED,AIRCRAFT	4	NS
164A168-1	2915-00-017-9021	PUMP,SUBMERGED,AIRCRAFT	3	SV
164A168-1	2915-00-018-0012	PUMP,SUBMERGED,AIRCRAFT	1	SV
16539B	5310-00-550-3671	NUT,PLAIN,HEXAGON	117	NS
1735475-02	2915-01-282-1772	FUEL FILTER	1	NS
1783755-615	5826-00-897-4889	INDICATOR,RADIO-MAGNETIC COMPASS	2	RP
18-32291-Z			5	NS
185/2018A	6620-00-624-7168	GAGE,PRESSURE,DIAL INDICATING	1	NS
189983-01	6615-00-601-7455		2	SV
1924-UHAR-3103	3110-00-701-9880	BEARING,ROLLER,JOURNAL	59	NS
1C3-4			1	OH
1C64-1	2915-01-124-5222	PUMP,SUBMERGED,AIRCRAFT	1	AR
200-011-100-131	1615-01-092-6746	HUB ASSEMBLY,MAIN R	15	NS
201-001-328-43			2	NS
201-010-422-021			14	NS
204-001-006-001	5340-00-765-6255	CLEVIS,ROD END	5	NS
204-001-006-1	5340-00-765-6255	CLEVIS,ROD END	1	NS
204-001-012-013	3040-00-624-5143	CONNECTING LINK,RIGID	1	AR
204-001-012-033			1	NS
204-001-012-13	3040-00-624-5143	CONNECTING LINK,RIGID	12	NS
204-001-014-7	3040-00-736-3999	CONNECTING LINK,RIGID	2	NS
204-001-016-13	3040-00-624-5122		9	NS
204-001-018-027	3040-00-775-7739	CONNECTING LINK,RIGID	2	NS
204-001-019-7	3040-00-886-5993	CONNECTING LINK,RIGID	1	AR
204-001-027-023			1	NS
204-001-027-23			6	NS
204-001-041-1			110	NS
204-001-042-001	1680-00-045-6642	CYLINDER ASSEMBLY,F	2	SV
204-001-042-001	1680-00-045-6642	CYLINDER ASSEMBLY,F	1	AR
204-001-042-1	1680-00-045-6642	CYLINDER ASSEMBLY,F	2	NS
204-001-042-1	1680-00-045-6642	CYLINDER ASSEMBLY,F	1	AR
204-001-042-5	1680-01-192-4912	CYLINDER ASSEMBLY,REACTION	1	NS
204-001-045-5	1680-00-767-4219	CYLINDER ASSEMBLY,REACTION	1	SV
204-001-045-5	1680-00-767-4219	CYLINDER ASSEMBLY,REACTION	9	NS
204-001-045-5	1680-00-767-4219	CYLINDER ASSEMBLY,REACTION	1	SV
204-001-045-9	1560-00-888-7348	FORCE GRADIENT ASSEMBLY,TORQUE	4	NS
204-001-045-9	1560-00-888-7348	FORCE GRADIENT ASSEMBLY,TORQUE	1	AR
204-001-064-003	3110-00-230-4837	BEARING,ROLLER,ROD END	1	NS
204-001-102-017			1	SV
204-001-110-001			1	NS
204-001-130-1			3	NS
204-001-185-005	1560-00-670-5901		2	NS
204-001-187-5			3	NS
204-001-189-001	5365-00-690-5259	SPACER,SLEEVE	1	NS
204-001-193-1	1560-00-624-5110	GUIDE,THROTTLE TUBE,COLLECTIVE SYSTEM	2	NS
204-001-196-3			2	NS
204-001-230-1	3020-00-633-0855	GEAR,BEVEL	2	NS
204-001-234-001	5315-00-837-9891	PIN,STRAIGHT,HEADLESS	3	NS
204-001-256-5	1560-00-936-9253	SHOE,FRICITION,COLLECTIVE STICK	1	NS
204-001-256-5C	1560-00-936-9253	SHOE,FRICITION,COLLECTIVE STICK	2	SV
204-001-268-17	1680-00-876-8760	BOOT ASSEMBLY	1	AR
204-001-275-005	5310-00-766-8597		1	NS
204-001-287-1			1	AR

204-001-298-1	1560-00-731-8091		1	NS
204-001-304-001			1	NS
204-001-334-009			1	AR
204-001-334-3	1680-00-084-7755	CONTROL STICK,AIRCRAFT	1	AR
204-001-334-5	1680-00-075-9377	CONTROL STICK,AIRCRAFT	1	NS
204-001-338-001			22	NS
204-001-338-3	4730-00-633-0878	ELBOW,CYCLIC CONTRO	1	NS
204-001-340-001	1560-00-670-7608	SUPPORT ASSEMBLY,CYCLIC CONTROL	1	NS
204-001-340-001	1560-00-670-7608	SUPPORT ASSEMBLY,CYCLIC CONTROL	3	NS
204-001-341-1	1560-00-633-0879	SUPPORT ASSEMBLY,COLLECTIVE,CYCLIC	3	NS
204-001-342-007	1680-00-413-1447	STICK,CYCLIC CONTRO	1	AR
204-001-345-1			1	NS
204-001-346-1	1560-00-670-7607	RING,DUST BOOT	11	NS
204-001-350-2	1560-00-980-9543		3	NS
204-001-353-1	3040-00-624-6741	CONNECTING LINK,RIGID	1	NS
204-001-357-001	1680-00-847-7438	LEVER ASSEMBLY,CYCLIC CONTROLS	2	NS
204-001-357-001	1680-00-847-7438	LEVER ASSEMBLY,CYCLIC CONTROLS	1	AR
204-001-357-1	1680-00-847-7438	LEVER ASSEMBLY,CYCLIC CONTROLS	1	AR
204-001-357-1	1680-00-847-7438	LEVER ASSEMBLY,CYCLIC CONTROLS	1	NS
204-001-362-001	1680-00-847-7440	SUPPORT,CYCLIC STICK	1	NS
204-001-362-1	1680-00-847-7440	SUPPORT,CYCLIC STICK	1	AR
204-001-366-1	1680-00-829-7863	BELL,CYCLIC STICK	4	NS
204-001-373-001	1680-00-758-3668	BELL CRANK	1	NS
204-001-373-1	1680-00-829-7863	BELL CRANK	1	SV
204-001-373-1	1680-00-758-3668	BELL CRANK	1	NS
204-001-376-003	1680-00-909-8716	BRAKE,MAGNETIC	1	NS
204-001-602-001	3040-00-859-2742	CONNECTING LINK,RIGID	1	NS
204-001-605-1	1680-00-875-8003	DOWNLOCK ASSEMBLY,C	4	NS
204-001-661-001	3040-00-912-0166		1	NS
204-001-661-1	1680-00-912-0166	CONNECTING LINK,RIGID	10	NS
204-001-663-1	1680-00-912-0167	CONNECTING LINK ASS	2	NS
204-001-700-3			1	NS
204-001-702-5	1680-00-986-9930	PAD,LEFT HAND,REMOV	1	NS
204-001-705-009	1560-00-981-6988		1	NS
204-001-710-005	1560-00-869-0706	PLATE ASSEMBLY,PEDAL	65	NS
204-001-710-1	1680-00-847-7443	PLATE,PEDAL ADJUSTE	2	NS
204-001-710-6	1560-00-869-0707	PLATE ASSEMBLY,PEDAL	1	NS
204-001-719-1	1560-00-624-6825	SUPPORT,BOOST CYLINDER	3	NS
204-001-724-5	1560-00-731-8090	LINK ASSEMBLY,TORQUE CONTROL	1	NS
204-001-739-3	1615-00-624-6963	CHAIN ASSY,SILENT	3	SV
204-001-762-017	1680-00-239-3677	NUT AND SUPPORT ASY	2	NS
204-001-762-13	1560-00-053-3949	ADJUSTER ASSEMBLY,ANTI-TORQUE	1	NS
204-001-763-43	1615-00-653-4351	PAN ASSY,TAIL ROTOR	1	NS
204-001-784-001	3040-00-625-0156	CONNECTING LINK,RIGID	13	NS
204-001-787-1			21	NS
204-001-792-009	4010-00-771-2512	WIRE ROPE ASSEMBLY,SINGLE LEG	6	NS
204-001-793-005	1560-00-653-4339	SUPPORT ASSEMBLY,QUADRANT	5	NS
204-001-793-5	1560-00-653-4339	SUPPORT ASSEMBLY,QUADRANT	6	NS
204-001-793-5	1560-00-653-4339	SUPPORT ASSEMBLY,QUADRANT	2	NS
204-001-795-005	1560-00-896-6265	SUPPORT ASSEMBLY,QUADRANT	10	NS
204-001-797-1			2	NS
204-001-800-1	1680-00-633-0818	BELL CRANK	1	NS
204-001-801-1	5365-00-707-7781	SPACER,SLEEVE	3	NS
204-001-802-001			1	AR
204-001-803-001	5340-00-721-6957		15	NS
204-001-808-3	5305-00-633-0830	SCREW,SHOULDER	1	NS
204-001-811-001			1	AR
204-001-813-001	1680-00-653-4333	BELL CRANK	20	NS
204-001-814-001	1560-00-653-4362	SUPPORT ASSEMBLY,BELL CRANK	1	NS
204-001-822-001	5342-00-779-0690	BRACKET,PULLEY,TAIL ROTOR CONTROL CABLE	1	NS
204-001-825-003	1560-00-931-8331	BRACKET,PULLEY,TAIL ROTOR	13	NS
204-001-832-1	1680-00-991-0318	BELL CRANK	1	NS
204-001-855-5	3040-00-076-9050	LEVER,REMOTE CONTROL	7	NS
204-001-858-001	1560-00-074-9014	COVER,ACCESS,AIRCRAFT	2	NS
204-001-858-1	1560-00-074-9014	COVER,ACCESS,AIRCRAFT	23	NS
204-001-924-3			2	NS

204-001-950-01	1560-00-804-2526	BELL CRANK	1	NS
204-010-116-001			1	NS
204-010-122-001			3	OH
204-010-128-1	5310-00-076-9864	WASHER,RECESSED	1	NS
204-010-128-1	5310-00-076-9864	WASHER,RECESSED	3	NS
204-010-150-001			15	NS
204-010-191-001	1615-00-624-5151	RESERVOIR,TRUNNION,MAIN ROTOR	2	NS
204-010-191-001	1615-00-624-5151	RESERVOIR,TRUNNION,MAIN ROTOR	35	SV
204-010-191-1	1615-00-624-5151	RESERVOIR,TRUNNION,MAIN ROTOR	1	NS
204-010-380-3			10	NS
204-010-389-5			7	NS
204-010-404-001	1680-00-847-8323	RING ASSEMBLY	1	AR
204-010-404-3	1615-00-649-8222	COLLAR,SHAFT	1	NS
204-010-405-001			2	SV
204-010-413-027	3120-00-848-6976	BUSHING,SLEEVE	16	NS
204-010-413-029	3120-00-848-6977	BUSHING,SLEEVE	4	NS
204-010-413-37	3120-00-474-9188	BUSHING,SLEEVE	2	NS
204-010-420-001	5310-00-649-8226	NUT,PLAIN,ROUND	7	NS
204-010-420-1	5310-00-649-8226	NUT,PLAIN,ROUND	2	NS
204-010-420-1	5310-00-649-8226	NUT,PLAIN,ROUND	1	NS
204-010-422-19	3130-00-707-3533	LINER,BEARING HOUSING	3	NS
204-010-433-001	3130-00-649-8227	BEARING UNIT,BALL	1	SV
204-010-433-1	3130-00-649-8227	BEARING UNIT,BALL	28	NS
204-010-457-005	5365-00-830-9727	SPACER,SLEEVE	4	NS
204-010-479-017	1615-00-454-8780	PLATE SET,COLLECTI	4	NS
204-010-481-001	5310-00-624-5116	NUT,PLAIN,SPLINE	2	NS
204-010-484-5			1	NS
204-010-494-1			47	NS
204-010-496-001	3120-01-252-4338	BUSHING,SLEEVE	2	NS
204-010-506-001	1615-00-670-7590	SIGHT GLASS,HUB	13	NS
204-010-506-001	1615-00-670-7590	SIGHT GLASS,HUB	35	SV
204-010-506-5	1615-00-873-2260	SIGHT GLASS,TRANSMISSION	1	NS
204-010-507-001	1615-00-624-6723	COVER,OIL RESERVOIR	1	SV
204-010-507-001	1615-00-624-6723	COVER,OIL RESERVOIR	32	SV
204-010-526-001	1615-00-670-2954		39	NS
204-010-529-1	1615-00-633-0828	COVER,RESERVOIR,TRUNNION	1	SV
204-010-529-1	1615-00-633-0828	COVER,RESERVOIR,TRUNNION	1	NS
204-010-532-1			123	NS
204-010-612-001			1	SV
204-010-704-9	3110-00-872-6968	BEARING,BALL,DUPLEX	7	SV
204-010-704-9	3110-00-872-6968	BEARING,BALL,DUPLEX	4	SV
204-010-708-3	5310-00-067-8028	NUT,PLAIN,ROUND	314	NS
204-010-709-001			2	NS
204-010-711-003	1615-00-836-8492	NUT,BEARING RETAINE	5	NS
204-010-711-1	1615-00-624-5321	NUT,BEARING RETAINE	10	NS
204-010-711-3	1615-00-836-8492	NUT,BEARING RETAINE	15	NS
204-010-712-5	5340-00-980-0345	RING,RADIUS	9	NS
204-010-719-001	5310-00-624-6714	NUT,PLAIN,ROUND	25	NS
204-010-719-1	5310-00-624-6714	NUT,PLAIN,ROUND	1	SV
204-010-719-1	5310-00-624-6714	NUT,PLAIN,ROUND	2	NS
204-010-720-003	1615-00-859-6111	SLIDER,TAIL ROTOR	10	NS
204-010-720-3	1615-00-859-6111	SLIDER,TAIL ROTOR	1	NS
204-010-720-3	1615-00-859-6111	SLIDER,TAIL ROTOR	93	NS
204-010-720-3	1615-00-859-6111	SLIDER,TAIL ROTOR	52	NS
204-010-720-3	1615-00-859-6111	SLIDER,TAIL ROTOR	48	NS
204-010-720-7	1615-00-350-4427	SLIDER,ROTARY RUDDER	15	NS
204-010-721-003	3110-00-973-3512	PLATE,RETAINING,BEARING	1	NS
204-010-721-3	3110-00-973-3512	PLATE,RETAINING,BEARING	97	NS
204-010-740-005	1615-01-074-0005		1	AR
204-010-747-3	1615-00-624-6719	GUARD,SPROCKET,TAIL ROTOR	1	SV
204-010-765-001	1615-00-691-2141	CONTROL NUT ASSY	15	NS
204-010-773-5	1615-00-736-4002	CROSSHEAD ASSEMBLY,	9	NS
204-010-774-011	1615-00-083-0468	STATIC STOP,TAIL ROTOR ASSEMBLY	2	NS
204-010-774-9	1615-00-896-6267	STATIC STOP,TAIL RO	61	NS
204-010-775-3	1615-00-815-6682	HOUSING,QUILL,TAIL ROTOR	1	SV
204-010-783-001	3110-00-784-0227	BEARING,ROLLER,NEEDLE	8	NS

204-010-783-1	3110-00-784-0227	BEARING,ROLLER,NEEDLE	2	SV
204-010-783-1	3110-00-784-0227	BEARING,ROLLER,NEEDLE	266	NS
204-010-783-1	3110-00-784-0227	BEARING,ROLLER,NEEDLE	177	NS
204-010-783-1	3110-00-784-0227	BEARING,ROLLER,NEEDLE	65	NS
204-010-783-1	3110-00-784-0227	BEARING,ROLLER,NEEDLE	1	SV
204-010-785-1	1615-00-771-2513	TRUNNION,TAIL ROTOR	7	NS
204-010-786-001	1615-00-785-3623	HOUSING,TRUNNION BE	3	NS
204-010-786-001	1615-00-785-3623	HOUSING,TRUNNION BE	2	SV
204-010-786-1	1615-00-785-3623	HOUSING,TRUNNION BE	2	SV
204-010-786-1	1615-00-785-3623	HOUSING,TRUNNION BE	2	SV
204-010-788-1	1615-00-780-2661	CAP ASSEMBLY,THRUST	4	SV
204-010-789-001	5365-00-785-3622	SHIM	1	NS
204-010-789-001	5365-00-785-3622	SHIM	1	NS
204-010-794-001	5365-00-758-3671	BUSHING,CROSSHEAD,TAIL ROTOR	2	NS
204-010-922-001			4	NS
204-010-922-003			15	NS
204-010-922-005	1615-00-830-9728	ADAPTER,STABILIZER	2	NS
204-010-922-007	1615-00-525-1385	ADAPTER,DAMPER MOUN	13	NS
204-010-922-009	1615-00-925-4143	ADAPTER ASSEMBLY,DA	1	NS
204-010-922-5	1615-00-830-9728	ADAPTER,STABILIZER	2	NS
204-010-925-009			1	NS
204-010-925-11	1560-00-885-3610		1	NS
204-010-937-007	1650-00-113-6354	DAMPENER,FLUTTER	1	SV
204-010-937-007	1650-00-113-6354	DAMPENER,FLUTTER	1	AR
204-010-937-7	1650-00-157-6843	DAMPENER,FLUTTER	1	OH
204-010-937-7	1650-00-157-6843	DAMPENER,FLUTTER	3	NS
204-011-007-5			3	NS
204-011-022-007	3120-00-783-2851	BUSHING,SLEEVE	1	NS
204-011-022-011	3120-00-789-2826	BUSHING,SLEEVE	1	NS
204-011-039-001	1615-00-830-9729	TAB,TRIM,ROTOR BLADE	1	AR
204-011-039-1	1560-00-830-9729	TAB,TRIM,ROTOR BLADE	40	NS
204-011-039-107	1615-01-143-7337	TAB,TRIM,ROTOR BLADE	1	NS
204-011-052-5	1615-00-239-3808	SUPPORT ASSY,WEIGHT	350	NS
204-011-062-001	1615-00-497-1960	TIP CAP,BLADE,ROTAR	4	NS
204-011-102-17	1615-00-757-2905		1	NS
204-011-105-1	1615-00-474-9224	TRUNNION ASSEMBLY	2	SV
204-011-108-3	1615-00-406-7717	PILLOW BLOCK	2	SV
204-011-108-3	1615-00-406-7717	PILLOW BLOCK	4	SV
204-011-110-3	3110-00-897-3803	BEARING,ROLLER,CYLINDRICAL	1	SV
204-011-111-003	3110-00-471-1756	BEARING,ROLLER,NEEDLE	2	SV
204-011-112-3	3110-00-409-5168	BEARING,ROLLER,NEEDLE	1	SV
204-011-116-1	5310-00-474-9240	NUT,PLAIN,SPLINE	3	SV
204-011-116-1	5310-00-474-9240	NUT,PLAIN,SPLINE	1	NS
204-011-118-001	3110-00-421-9148		2	NS
204-011-119-001	3120-00-839-0971	BEARING,PLAIN,ROD END	7	NS
204-011-120-001			5	NS
204-011-120-5	1615-00-085-3887	PITCH HORN ASSEMBLY	1	SV
204-011-120-5	1615-00-085-3887	PITCH HORN ASSEMBLY	5	SV
204-011-122-1	3130-00-474-9146	HOUSING,BEARING UNIT	2	NS
204-011-122-3			2	SV
204-011-123-001	5365-00-446-6372	SPACER,RING	1	AR
204-011-123-1	5365-00-446-6372	SPACER,RING	2	SV
204-011-123-1	5365-00-446-6372	SPACER,RING	2	NS
204-011-125-005	1560-01-041-7058	PLATE ASSEMBLY	1	NS
204-011-125-1	1560-00-446-6374	PLATE ASSEMBLY	1	SV
204-011-125-5	1560-01-041-7058	PLATE ASSEMBLY	6	NS
204-011-128-001	1615-00-829-6855	UNIVERSAL,CONTROL L	16	NS
204-011-128-001	1615-00-829-6855	UNIVERSAL,CONTROL L	6	NS
204-011-128-001	1615-00-829-6855	UNIVERSAL,CONTROL L	5	SV
204-011-129-001	3120-00-446-6376	BUSHING,SLEEVE	1	NS
204-011-129-1	3120-00-446-6376	BUSHING,SLEEVE	4	NS
204-011-131-005	5330-00-753-4409	SEAL	2	NS
204-011-135-003	3120-00-954-6363	BUSHING,SLEEVE	130	NS
204-011-135-003	3120-00-954-6363	BUSHING,SLEEVE	3	NS
204-011-135-3	3120-00-954-6363	BUSHING,SLEEVE	2	SV
204-011-135-3	3120-00-954-6363	BUSHING,SLEEVE	2	SV

204-011-136-1	5340-00-839-3934	CLEVIS,ROD END	1	AR
204-011-143-1	5306-00-830-9733	ROD,THREADED END	4	SV
204-011-144-003	1560-00-830-9735	NUT,DRAG BRACE	5	NS
204-011-144-003	1560-00-830-9735	NUT,DRAG BRACE	1	OH
204-011-144-003	1560-00-830-9735	NUT,DRAG BRACE	1	SV
204-011-144-3	1560-00-830-9735	NUT,DRAG BRACE	3	SV
204-011-147-001	5365-00-758-3674	SHIM	1	NS
204-011-147-001	5365-00-758-3674	SHIM	36	NS
204-011-147-1	5365-00-758-3674	SHIM	33	NS
204-011-147-1	5365-00-758-3674	SHIM	13	NS
204-011-151-001	1615-00-830-9736	BOLT ASSEMBLY,MAIN ROTOR	2	NS
204-011-151-5	5342-00-195-9842	PLUG	14	NS
204-011-151-7	5306-00-402-7979	BOLT	3	SV
204-011-152-1	5310-00-839-0972	WASHER,RECESSED	5	SV
204-011-153-001	5310-00-830-9737	NUT,PLAIN,ROUND	3	NS
204-011-153-1	5310-00-830-9737	NUT,PLAIN,ROUND	1	NS
204-011-153-1	5310-00-830-9737	NUT,PLAIN,ROUND	5	SV
204-011-159-1	1615-00-898-0048	SPACER,MAIN ROTOR GRIP	4	NS
204-011-160-001	5365-00-446-6379	SPACER,SLEEVE	3	NS
204-011-160-1	5365-00-446-6379	SPACER,SLEEVE	4	NS
204-011-162-001	5365-00-758-3676	SHIM	16	NS
204-011-162-001	5365-00-758-3676	SHIM	16	NS
204-011-162-001	5365-00-758-3676	SHIM	24	NS
204-011-162-011	5365-00-758-3676	SHIM	12	NS
204-011-164-001	1615-00-758-2828	STOP,INBOARD FITTING	1	NS
204-011-164-001	1615-00-758-2828	STOP,INBOARD FITTING	6	NS
204-011-166-003	5306-00-768-7506	BOLT,SHEAR	8	NS
204-011-166-3	5306-00-768-7506	BOLT,SHEAR	2	SV
204-011-166-3	5306-00-768-7506	BOLT,SHEAR	2	NS
204-011-180-1	1615-00-230-3886	FITTING,DRAG BRACE	4	SV
204-011-1B84-1			4	SV
204-011-211-1	1615-00-051-3646	CROSSHEAD ASSEMBLY	2	SV
204-011-215-007			9	NS
204-011-301-005			3	SV
204-011-301-005			1	NS
204-011-303-7	1615-00-829-6857	WEIGHT,ROTARY WING HEAD	6	NS
204-011-304-001	1560-00-830-9741	SUPPORT ASSEMBLY,STABILIZER	1	NS
204-011-304-1	1560-00-830-9741	SUPPORT ASSEMBLY,STABILIZER	1	NS
204-011-305-1	1615-00-830-9742	FITTING,TIE ROD,STA	14	NS
204-011-311-1	5310-00-893-4392	WASHER,FLAT	12	NS
204-011-313-001	1680-00-830-9745	LEVER,REMOTE CONTROL	1	NS
204-011-313-011	1680-00-830-9745	LEVER,REMOTE CONTROL	1	SV
204-011-329-001	4010-00-764-8673	WIRE ROPE ASSEMBLY,SINGLE LEG	1	NS
204-011-334-1	5330-00-7810791		8	NS
204-011-400-011	1615-00-060-1062	SWASHPLATE,CONTROLLABLE	1	AR
204-011-401-11	1615-00-454-8828	SCISSORS AND SLEEVE	123	RP
204-011-402-013	1615-00-060-1058	SWASHPLATE,CONTROLLABLE	2	NS
204-011-402-017	1615-00-225-1963	INNER RING ASSY,SWA	1	NS
204-011-402-13	1615-00-060-1058	SWASHPLATE,CONTROLLABLE	3	NS
204-011-402-13	1615-00-060-1058	SWASHPLATE,CONTROLLABLE	3	NS
204-011-403-1	1615-00-474-9151	RING ASSEMBLY,OUTER	2	NS
204-011-403-1	1615-00-474-9151	RING ASSEMBLY,OUTER	1	NS
204-011-403-1	1615-00-474-9151	RING ASSEMBLY,OUTER	2	NS
204-011-404-013	1615-00-509-2227	SUPPORT ASSEMBLY,SWASH PLATE	3	NS
204-011-404-125			1	NS
204-011-405-009	1615-00-970-1259	HUB ASSEMBLY,COLLEC	1	NS
204-011-406-013	1615-00-938-9784	SCISSORS ASSEMBLY	1	NS
204-011-406-13	1615-00-938-9784	SCISSORS ASSEMBLY	8	NS
204-011-409-001	3110-00-855-9236	BEARING,BALL,STACK	8	NS
204-011-409-1	3110-00-855-9236	BEARING,BALL,STACK WITH FAA CERTS	1	SV
204-011-409-1	3110-00-855-9236	BEARING,BALL,STACK	2	NS
204-011-409-1	3110-00-855-9236	BEARING,BALL,STACK	2	NS
204-011-409-1	3110-00-855-9236	BEARING,BALL,STACK	3	NS
204-011-412-001	3110-00-731-7977	BEARING,BALL,STACK	2	NS
204-011-412-001	3100-00-317-7377		16	NE
204-011-412-001	3100-00-317-7377		13	NS

204-011-412-1	3110-00-731-7977	BEARING,BALL,STACK	1	NS
204-011-412-1	3110-00-731-7977	BEARING,BALL,STACK	1	NS
204-011-412-1	3110-00-731-7977	BEARING,BALL,STACK	1	NS
204-011-418-1	3110-00-840-8610	BEARING,ROLLER,JOURNAL	1	NS
204-011-421-001	1615-00-830-9751	HOUSING ASSEMBLY,DRIVE LINK	8	NS
204-011-421-1	1615-00-830-9751	HOUSING ASSEMBLY,DRIVE LINK	1	NS
204-011-421-1	1615-00-830-9751	HOUSING ASSEMBLY,DRIVE LINK	1	NS
204-011-428-3	3110-00-876-2410	PLATE,RETAINING,BEARING	1	NS
204-011-431-1	5365-00-446-6387	SHIM	1	NS
204-011-438-1	1615-00-830-9754	LEVER ASSEMBLY,PYLO	6	NE
204-011-438-1	1615-00-830-9754	LEVER ASSEMBLY,PYLO	15	NS
204-011-438-1	1615-00-830-9754	LEVER ASSEMBLY,PYLO	2	SV
204-011-441-001	3120-00-847-2707	BUSHING,SLEEVE	6	NS
204-011-442-00	3040-00-830-9755	CONNECTING LINK,RIGID	13	NS
204-011-442-00	3040-00-830-9755	CONNECTING LINK,RIGID	1	AR
204-011-442-001	3040-00-830-9755	CONNECTING LINK,RIGID	6	NS
204-011-443-001	3130-00-830-9756	BEARING UNIT,BALL	5	NS
204-011-446-003	5315-00-718-6798	PIN,SHOULDER,HEADLESS	4	NS
204-011-451-001	1615-00-970-1262	TRUNNION ASSEMBLY,SWASHPLATE	1	SV
204-011-453-1	5315-00-860-9527	PIN	43	NS
204-011-460-001	5365-00-078-5878	SPACER,SLEEVE	2	NS
204-011-463-3	5306-00-533-8774	BOLT,SHEAR	85	NS
204-011-495-009			1	NS
204-011-597-1			1	AR
204-011-701-023	1615-00-990-3101	HUB,TAIL ROTOR	1	AR
204-011-704-9			2	SV
204-011-706-01E			3	AR
204-011-706-17	1615-00-060-1064	GRIP ASSY,TAIL,ROTO	1	NS
204-011-706-21	1615-00-077-2451	GRIP ASSEMBLY,TAIL	13	NS
204-011-707-001	1615-00-898-1688	LOCKPLATE,GRIP NUT	126	NS
204-011-707-1	1615-00-898-1688	LOCKPLATE,GRIP NUT	2	NS
204-011-711-001	1615-00-051-3646	CROSSHEAD ASSEMBLY	8	SV
204-011-711-001	1615-00-051-3646	CROSSHEAD ASSEMBLY	1	NS
204-011-716-1	5365-00-871-8756	RING,OUTER,THRUST U	15	NS
204-011-720-001	1615-00-111-3622	CONE SET,TAIL ROTOR	16	NS
204-011-720-001	1615-00-111-3622	CONE SET,TAIL ROTOR	1	SV
204-011-720-1	1615-00-111-3622	CONE SET,TAIL ROTOR	7	SV
204-011-720-1	1615-00-111-3622	CONE SET,TAIL ROTOR	1	NS
204-011-721-001	5365-00-111-5525	SPACER,RING	2	SV
204-011-721-1	5365-00-111-5525	SPACER,RING	3	SV
204-011-721-1	5365-00-111-5525	SPACER,RING	14	SV
204-011-722-005	1615-00-111-3623	YOKE ASSEMBLY,ROTOR	1	AR
204-011-722-5	1615-00-111-3623	YOKE ASSEMBLY,ROTOR	1	AR
204-011-723-001	5310-00-115-9403	NUT,PLAIN,ROUND	13	NS
204-011-723-001	5310-00-115-9403	NUT,PLAIN,ROUND	2	NS
204-011-723-1	5310-00-115-9403	NUT,PLAIN,ROUND	1	SV
204-011-723-1	5310-00-115-9403	NUT,PLAIN,ROUND	8	SV
204-011-723-1	5310-00-115-9403	NUT,PLAIN,ROUND	2	SV
204-011-723-1	5310-00-115-9403	NUT,PLAIN,ROUND	4	NS
204-011-725-1	1615-00-113-6176	SPRING ASSEMBLY,PRELOAD	12	SV
204-011-726-001	1615-00-113-6175	PLUG,THRUST	4	NS
204-011-726-1	1615-00-113-6175	PLUG,THRUST	4	NS
204-011-728-001	1615-00-488-7600	GRIP ASSY,ROTOR TAI	17	NS
204-011-728-5			1	NS
204-011-731-001	5365-00-113-1416	SPACER,SLEEVE	2	SV
204-011-731-1	5365-00-113-1416	SPACER,SLEEVE	5	SV
204-011-732-1	5365-00-113-6174	SPACER,RING	2	SV
204-011-732-1	5365-00-113-6174	SPACER,RING	5	SV
204-011-732-1	1615-00-113-6174	SPACER,RING	43	NS
204-011-732-1	5365-00-113-6174	SPACER,RING	1	SV
204-011-732-1	5365-00-113-6174	SPACER,RING	5	NS
204-011-737-005	1615-00-132-4932	TRUNNION ASSY,TAIL ROTOR	9	NS
204-011-737-1	1615-00-135-2550	TRUNNION ASSY,TAIL ROTOR	1	NS
204-011-737-1	1615-00-135-2550	TRUNNION ASSY,TAIL ROTOR	1	SV
204-011-762-011	3060-00-157-5087	CONNECTING LINK,RIGID	12	NS
204-011-762-11	3040-00-157-5087	CONNECTING LINK,RIGID	2	NS

204-012-101-141	1615-01-270-2982	HUB,ROTOR,HELICOPTER	2	AR
204-012-102-005	1615-00-848-4888	FITTING ASSEMBLY,RETENTION STRAP	2	SV
204-012-102-9	1615-01-379-8819	FITTING ASSEMBLY	4	SV
204-012-102-9	1615-01-379-8819	FITTING ASSEMBLY	1	NS
204-012-103-001	1615-00-200-7454	FITTING,HUB ASSEMBL	4	SV
204-012-103-001	1615-00-200-7454	FITTING,HUB ASSEMBL	2	AR
204-012-104-005	5315-00-834-1418	PIN,STRAIGHT,HEADLESS	2	SV
204-012-104-005	5315-00-834-1418	PIN,STRAIGHT,HEADLESS	8	SV
204-012-106-001	5310-00-142-2449	NUT,PLAIN,INTERNAL WRENCHING	8	NS
204-012-106-001	5310-00-142-2449	NUT,PLAIN,INTERNAL WRENCHING	1	SV
204-012-106-1	5310-00-142-2449	NUT,PLAIN,INTERNAL WRENCHING	4	NS
204-012-108-001	1560-00-757-1469	STOP,INBOARD FITTING	16	NS
204-012-116-1	1615-00-865-7911	SHIELD ASSEMBLY,ROT	74	NS
204-012-116-3	1615-00-201-3782	SHIELD ASSEMBLY,MAIN ROTOR	2	NS
204-012-122-7	1615-01-063-4015	STRAP ASSEMBLY	2	NS
204-015-011-1	1615-01-060-0728	COVER,SPLICE	2	NS
204-020-105-1			3	NS
204-020-413-029			4	NS
204-026-268-001			1	NS
204-030-091-3	1560-00-928-6257	SUPPORT,FUEL TANK	8	NS
204-030-092-1	1560-00-869-9003	BRACE,PYLON	2	NS
204-030-164-042			1	NS
204-030-196-001	5340-00-671-4431	BOOT,DUST AND MOISTURE SEAL	1	NS
204-030-196-15	5340-00-690-7284	BOOT,DUST AND MOISTURE SEAL	1	NS
204-030-196-5	5340-00-671-4434	BOOT,DUST AND MOISTURE SEAL	3	NS
204-030-220-1	1560-00-872-7860	SLIDE ASSEMBLY,CARGO	5	NS
204-030-227-001	1560-00-701-9918	RETAINER,CARGO DOOR	1	NS
204-030-283-1	5340-00-671-4421	HINGE,ACCESS DOOR	5	NS
204-030-284-1	5340-00-671-4423		4	NS
204-030-285-1	5340-00-671-4425		26	NS
204-030-286-001	5340-00-671-4427	HINGE,ACCESS DOOR	2	NS
204-030-287-085	1560-00-843-1224	DOOR,ACCESS,AIRCRAFT	1	SV
204-030-349-003			17	NS
204-030-353-003	1560-00-672-0080	STOP ASSEMBLY,DOOR	9	NS
204-030-362-007	5306-00-738-8384	BOLT,ISOLATION MOUN	3	NS
204-030-399-007	4720-00-739-4590	TUBING,NONMETALLIC	4	NS
204-030-458-1	1560-00-997-6639	RETAINER,WINDOW	42	NS
204-030-477-009	4720-00-894-6534	HOSE,NONMETALLIC	8	NS
204-030-482-002	1560-00-759-7486	BELL CRANK	1	NS
204-030-483-003	1560-00-765-7818	ROD ASSEMBLY,CREW DOOR LATCH	1	SV
204-030-620-003	1560-00-869-6311	PAN,AIR VENT DRAIN	1	NS
204-030-620-003	1560-00-869-6311	PAN,AIR VENT DRAIN	1	AR
204-030-646-33	1560-00-875-8000	SUPPORT,STRUCTURAL COMPONENT,AIRCRAFT	1	NS
204-030-646-34	1560-00-875-8001	SUPPORT,STRUCTURAL COMPONENT,AIRCRAFT	1	NS
204-030-647-9	1560-00-672-0070	PLUNGER ASSEMBLY,DOOR	1	NS
204-030-658-9	1560-00-701-4134		2	NS
204-030-664-41A	1560-00-102-8570	SKIN AND SUPPORT ASSEMBLY	6	NS
204-030-664-41A	1560-00-102-8570	SKIN AND SUPPORT ASSEMBLY	9	NS
204-030-664-41A	1560-00-102-8570	SKIN AND SUPPORT ASSEMBLY	10	NS
204-030-66-5			3	NS
204-030-671-4	1560-00-624-6785	SUPPORT ASSEMBLY,ANTENNA	1	NS
204-030-673-57	1560-00-420-8004	WINDOW PANEL,AIRCRAFT	10	NS
204-030-696-007	1560-00-653-4328	BRACKET,ROLLER,CARGO DOOR	5	NS
204-030-719-1			2	NS
204-030-726-4	1560-00-738-8330	PLATE,DOOR STRIKER	16	NS
204-030-731-1	5360-01-224-6016	SPRING,HELICAL,EXTENSION	10	NS
204-030-731-1	5360-01-224-6016	SPRING,HELICAL,EXTENSION	10	NS
204-030-763-1	1560-00-939-5948	FITTING,HINGE,DOOR	50	NS
204-030-769-6			1	NS
204-030-770-1	1560-00-690-7288	WINDOW PANEL,AIRCRAFT	5	NS
204-030-815-1	1560-00-916-2530	FITTING,STRUCTURAL COMPONENT,AIRCRAFT	1	NS
204-030-818-101			2	NS
204-030-824-4	1560-00-771-2511	PLATE,STRIKER,RIGHT HAND	2	NS
204-030-827-453			1	NS
204-030-838-013			2	NS
204-030-861-1	5305-00-701-7564	SCREW,SHOULDER	1	NS

204-030-885-1	1560-00-674-4195	HANDLE ASSEMBLY,CARGO DOOR	33	NS
204-030-888-1	1560-00-701-4140	PAN ASSEMBLY,CARGO DOOR	6	NS
204-030-919-39	1560-00-869-8945	BLOCK,RADIUS,PYLON	6	NS
204-030-922-003	5340-00-633-0856	BOOT,DUST AND MOISTURE SEAL	1	NS
204-030-922-003	5340-00-633-0856	BOOT,DUST AND MOISTURE SEAL	6	AR
204-030-926-4	1560-00-847-7506	SUPPORT,COWL	1	NS
204-030-931-005	5365-01-328-2528		1	NS
204-030-962-001	5355-00-727-4961	KNOB	14	NS
204-030-987-1	1560-00-894-6535	LINK ASSEMBLY,LIFT	1	NS
204-031-009-17			1	NS
204-031-105-7			30	NS
204-031-136-13			7	NS
204-031-139-3			6	NS
204-031-196-1	1560-00-739-2572	BOOT,CONTROL TUBE	3	NS
204-031-200-001	1560-00-929-8439	PLATE,STRIKER GUIDE	2	NS
204-031-200-003	1560-00-929-8440	PLATE,STRIKER GUIDE	2	NS
204-031-212-003	1560-00-736-4015	CABLE ASSEMBLY	13	NS
204-031-227-5	1560-00-997-6617	BRACKET,FUSELAGE	1	SV
204-031-246-009	1560-00-757-2868	SUPPORT,STRUCTURAL COMPONENT,AIRCRAFT	10	NS
204-031-246-2			3	NS
204-031-248-3	1560-00-070-6831	PLATE,STRUCTURAL,AIRCRAFT	60	NS
204-031-253-001	1560-00-894-6537	HANDLE,LATCH	9	NS
204-031-254-1	1560-00-739-4564	HOOK ASSEMBLY,CARGO DOOR	2	NS
204-031-275-001	1615-00-075-0286	MOUNT ASSEMBLY	11	NS
204-031-292-1			39	NS
204-031-323-21	1560-00-794-2580	COVER,ACCESS	1	NS
204-031-468-2	5340-00-736-4034	HINGE,ACCESS DOOR	1	NS
204-031-486-1			1	NS
204-031-503-2			2	NS
204-031-574-19			1	NS
204-031-668-105			11	NS
204-031-762-001	5360-00-738-8354	SPRING,HINGE PLATE	2	NS
204-031-762-002	5360-00-738-8355	SPRING,HINGE PLATE	3	NS
204-031-762-1	1560-00-738-8354	SPRING,HINGE PLATE	3	NS
204-031-762-5	1560-00-739-4565	SPRING,HINGE PLATE	6	NS
204-031-837-006	5365-00-998-7625	SHIM	1	NS
204-031-837-006	5365-00-998-7625	SHIM	6	NS
204-031-837-012	5340-00-757-4849	HINGE,ACCESS DOOR	1	NS
204-031-919-84	1560-00-994-6001	CHANNEL,SUPPORT	1	NS
204-031-927-007	5342-00-739-4569	MOUNT,RESILIENT,WEAPON SYSTEM	1	NS
204-031-927-007	5342-00-739-4569	MOUNT,RESILIENT,WEAPON SYSTEM	5	NS
204-031-927-5	5342-00-739-4568	MOUNT,RESILIENT,WEAPON SYSTEM	3	SV
204-031-927-7	5342-00-739-4569	MOUNT,RESILIENT,WEAPON SYSTEM	10	AR
204-032-219-017			4	AR
204-032-259-029	1560-00-927-5755	STRAP ASSEMBLY,CARGO	2	NS
204-032-668-7			1	NS
204-040-003-27	1615-00-766-8592	QUILL ASSEMBLY,GEAR	6	NS
204-040-003-35	1615-00-760-3313	QUILL ASSEMBLY,GEAR	8	NS
204-040-003-37	1615-00-918-2676	GEAR BOX ASSEMBLY,T	7	OH
204-040-010-7	1615-00-863-3819	DRIVE SHAFT ASSEMBL	1	OH
204-040-010-7	1615-00-863-3819	DRIVE SHAFT ASSEMBL	1	NS
204-040-010-7	1615-00-863-3819	DRIVE SHAFT ASSEMBL	1	OH
204-040-012-011	1615-00-760-3315	QUILL ASSEMBLY,GEAR	1	AR
204-040-012-013	3040-00-918-2677	GEARSHAFT,BEVEL	1	NS
204-040-012-013	1615-00-918-2677	GEARSHAFT,BEVEL	5	NS
204-040-012-013	3040-00-918-2677	GEARSHAFT,BEVEL	4	NS
204-040-012-13	3040-00-918-2677	GEARSHAFT,BEVEL	2	OH
204-040-012-13	3040-00-918-2677	GEARSHAFT,BEVEL	1	NS
204-040-016-005	1680-00-183-0834	TRANSMISSION ASSY,H	6	AR
204-040-100-13			1	OH
204-040-104-001			41	AR
204-040-108-007	3020-00-898-6886	GEAR,SPUR	5	NS
204-040-108-007	3020-00-898-6886	GEAR,SPUR	6	NS
204-040-108-7	3020-00-898-6886	GEAR,SPUR	54	NS
204-040-108-7	3020-00-898-6886	GEAR,SPUR	1	NS
204-040-108-7	3020-00-898-6886	GEAR,SPUR	2	NS

204-040-108-7	3020-00-898-6886	GEAR,SPUR	3	NS
204-040-115-001	5310-00-625-0127	NUT,SELF-LOCKING,SPLINE	43	NS
204-040-116-003	1615-00-859-6163	LOCKWASHER,TRANSMISSION	6	SV
204-040-116-3	1615-00-859-6163	LOCKWASHER,TRANSMISSION	16	NS
204-040-116-3	1615-00-859-6163	LOCKWASHER,TRANSMISSION	2	NS
204-040-117-3	1615-00-859-6112	ADAPTER,MAST DRIVIN	1	OH
204-040-121-005	3040-00-787-4256	GEARSHAFT,SPUR	1	NS
204-040-121-005	3040-00-787-4256	GEARSHAFT,SPUR	2	NS
204-040-121-005	3040-00-787-4256	GEARSHAFT,SPUR	2	OH
204-040-121-5	3040-00-787-4256	GEARSHAFT,SPUR	1	OH
204-040-122-001	5310-00-713-8354	NUT,PLAIN,SPLINE	4	NS
204-040-123-001	1615-00-624-5250	RING,LOCKING,GEARSH	2	SV
204-040-130-005	1615-00-787-4273	SHAFT,SHOULDERED	4	SV
204-040-131-001	5310-00-624-5251	NUT,BEARING	36	SV
204-040-131-1	5310-00-624-5251	NUT,BEARING	12	SV
204-040-142-001	3110-00-726-4896	BEARING,BALL,ANNULAR	2	NS
204-040-143-001	3110-00-625-0114	BEARING,BALL,DUPLEX	2	AR
204-040-148-3	1615-00-859-6113	PLATE,RETAINING,BEARING	1	NS
204-040-148-3	1615-00-859-6113	PLATE,RETAINING,BEARING	13	NS
204-040-149-013	1560-00-815-6679		1	NS
204-040-151-13			3	AR
204-040-159-3	3110-00-708-2281	PLATE,RETAINING,BEARING	1	SV
204-040-163-005	5330-00-859-8062	GASKET	1	NS
204-040-166-101			1	NS
204-040-168-001	3130-00-797-2433	LINER,BEARING HOUSING	2	NS
204-040-168-1	3130-00-797-2433	LINER,BEARING HOUSING	2	NS
204-040-170-005	3120-00-439-8473	BEARING,SLEEVE	4	NS
204-040-170-5	3120-00-439-8473	BEARING,SLEEVE	1	NS
204-040-174-001	1615-00-898-1684	COVER ASSEMBLY,QUILL PAD	3	NS
204-040-180-1	1615-00-491-0880	PLATE,TAIL ROTOR DR	24	NS
204-040-180-1	1615-00-491-0880	PLATE,TAIL ROTOR DR	6	NS
204-040-183-001	5340-00-714-5446	CLIP,RETAINING	22	SV
204-040-184-001	1615-00-977-7079	NUT,SPLINED,TRANSMISSION	1	SV
204-040-184-001	1615-00-977-7079	NUT,SPLINED,TRANSMISSION	5	AR
204-040-184-001	1615-00-977-7079	NUT,SPLINED,TRANSMISSION	38	NS
204-040-184-001	1615-00-977-7079	NUT,SPLINED,TRANSMISSION	10	NS
204-040-184-1	1615-00-977-7079	NUT,SPLINED,TRANSMISSION	16	NS
204-040-184-1	1615-00-977-7079	NUT,SPLINED,TRANSMISSION	8	SV
204-040-185-003	5365-00-772-6135	RING,EXTERNALLY THREADED	4	NS
204-040-185-003	5365-00-772-6135	RING,EXTERNALLY THREADED	1	OH
204-040-185-1	5365-00-797-2437	RING,EXTERNALLY THREADED	1	AR
204-040-185-3	5365-00-772-6135	RING,EXTERNALLY THREADED	1	SV
204-040-1861	5310-00-709-8601	NUT,PLAIN,SPLINE	22	NS
204-040-189-001	5365-00-713-8353	SPACER SET,RING	1	NS
204-040-189-9			5	NS
204-040-190-001			1	NS
204-040-190-101	3110-00-765-4409	RING,BEARING,INNER	1	NS
204-040-191-007	1615-00-765-4408	RACE,OUTER,QUILL	1	NS
204-040-191-7	1615-00-765-4408	RACE,OUTER,QUILL	1	NS
204-040-199-001	3110-00-625-0133	PLATE,RETAINING,BEARING	1	OH
204-040-201-1			1	NS
204-040-207-013	1615-00-795-0661	QUILL ASSEMBLY,TAIL	3	OH
204-040-207-013	1615-00-795-0661	QUILL ASSEMBLY,TAIL	1	NE
204-040-223-011	4710-00-859-6114	TUBE,METALLIC	1	OH
204-040-223-11	4710-00-859-6114	TUBE,METALLIC	1	SV
204-040-227-1	5360-00-691-2158	SPRING,HELICAL,COMPRESSION	3	NS
204-040-230-1	5310-00-797-2438	NUT,PLAIN,SPLINE	24	NS
204-040-234-001	1615-00-701-9879	PLUG,OIL,TRANSMISSION	1	NS
204-040-234-1	1615-00-701-9879	PLUG,OIL,TRANSMISSION	3	AR
204-040-237-001	1615-00-624-5245	SCREEN ASSY,PUMP INLET	1	NS
204-040-237-1	1615-00-624-5245	SCREEN ASSY,PUMP INLET	1	NS
204-040-244-001	5330-00-875-7988	SEAL,PLAIN	9	NS
204-040-244-001	5330-00-875-7988	SEAL,PLAIN	1	NS
204-040-250-009	1680-00-784-0231	HOUSING,COUPLING	1	SV
204-040-251-1	3110-00-708-2283	PLATE,RETAINING,BEARING	78	NS
204-040-257-001	1615-00-691-2163	LINER,TRANSMISSION	1	NS

204-040-261-013	1615-00-898-6884	JET LUBRICATOR,TRANSMISSION	1	AR
204-040-271-003	3110-00-701-9880	BEARING,ROLLER,JOURNAL	50	NS
204-040-271-003	3110-00-701-9880	BEARING,ROLLER,JOURNAL	3	NS
204-040-271-003	3110-00-701-9880	BEARING,ROLLER,JOURNAL	3	NS
204-040-298-001	1651-00-797-1032	JET,OIL	10	NS
204-040-305-001	1615-00-798-3643	SLEEVE ASSEMBLY,TAI	3	NS
204-040-305-1	1615-00-798-3643	SLEEVE ASSEMBLY,TAI	2	NS
204-040-307-001	3130-00-765-2389	LINER,BEARING HOUSING	3	NS
204-040-307-001	3130-00-765-2389	LINER,BEARING HOUSING	1	NS
204-040-307-001	3130-00-765-2389	LINER,BEARING HOUSING	4	NS
204-040-307-001	3130-00-765-2389	LINER,BEARING HOUSING	15	NS
204-040-308-001	1615-00-701-9884	RING,CENTERING,TRANSMISSION	1	NS
204-040-310-001	3110-00-822-2130	BEARING,ROLLER,CYLINDRICAL	27	NS
204-040-310-001	3110-00-822-2130	BEARING,ROLLER,CYLINDRICAL	50	NS
204-040-310-001	3110-00-822-2130	BEARING,ROLLER,CYLINDRICAL	24	AR
204-040-310-001	3110-00-822-2130	BEARING,ROLLER,CYLINDRICAL	5	NS
204-040-310-003			7	NS
204-040-310-003			3	NS
204-040-313-001	5365-00-775-7744	SPACER,SLEEVE	2	NS
204-040-313-1	5365-00-775-7744	SPACER,SLEEVE	1	NS
204-040-321-001	1615-00-701-9940	SUPPORT,TRANSMISSION	2	NE
204-040-322-001	5340-00-701-9941	CLIP,RETAINING	375	NS
204-040-324-005	1615-00-918-1912	SHAFT,MAIN GEAR,TRA	3	NS
204-040-324-005	1615-00-918-1912	SHAFT,MAIN GEAR,TRA	3	NS
204-040-331-5	1615-00-893-3442	CASE,TRANSMISSION	1	NE
204-040-338-001	1615-00-898-6890	LINER,BEARING SUPPORT	1	OH
204-040-338-1	1615-00-898-6890	LINER,BEARING SUPPORT	1	NS
204-040-339-5	1616-XX-859-2745		2	NS
204-040-341-1	1615-00-830-9764	TUBE,OIL DRAIN,TRANSMISSION	1	SV
204-040-342-001	1615-00-829-6842	RETAINER,OIL SEAL	5	NS
204-040-342-001	1615-00-829-6842	RETAINER,OIL SEAL	4	NS
204-040-347-001	3110-00-829-6843	PLATE,RETAINING,BEARING	5	NS
204-040-349-009	1615-00-070-6821	PLATE ASSEMBLY	2	NS
204-040-350-1	5365-00-758-3691	SHIM	1	NS
204-040-355-5	3040-00-950-6840	HOUSING,MECHANICAL DRIVE	1	SV
204-040-357-005	3110-00-061-5312	PLATE,RETAINING,BEARING	14	NS
204-040-357-005	3110-00-061-5312	PLATE,RETAINING,BEARING	2	OH
204-040-357-005	3110-00-061-5312	PLATE,RETAINING,BEARING	1	NS
204-040-366-1	1615-00-255-2896	MAST,ROTOR,HELICOPTER	3	NS
204-040-368-001	4730-00-988-4533	FITTING,LUBRICANT PRESSURE RELIEF	3	AR
204-040-378-1	1615-00-898-1685	DEFLECTOR,DIRT AND LIQUID	2	SV
204-040-379-003	1615-00-056-4869	QUILL ASSEMBLY,GENE	1	OH
204-040-387-005	1560-00-876-8761	MANIFOLD ASSEMBLY,OIL TRANSMISSION	1	NS
204-040-387-005	1560-00-876-8761	MANIFOLD ASSEMBLY,OIL TRANSMISSION	1	SV
204-040-387-005	1560-00-876-8761	MANIFOLD ASSEMBLY,OIL TRANSMISSION	2	NS
204-040-397-1	1615-00-874-0862	SPIDER ASSEMBLY	1	NS
204-040-397-1	1615-00-874-0862	SPIDER ASSEMBLY	1	NS
204-040-397-3	1615-00-874-0863	SPIDER ASSEMBLY	1	SV
204-040-398-1	4730-00-740-3366	FITTING,LUBRICATION	108	NS
204-040-400-009	3040-00-787-4269	GEARSHAFT,BEVEL	1	NS
204-040-400-009	3040-00-787-4269	GEARSHAFT,BEVEL	2	NS
204-040-400-9	1615-00-787-4269	GEARSHAFT,BEVEL	7	NS
204-040-401-007	3020-00-787-4267	GEAR,BEVEL	5	AR
204-040-401-7	3020-00-787-4267	GEAR,BEVEL	1	SV
204-040-402-009	1615-00-787-4268	SHAFT,TAIL ROTOR	1	NS
204-040-405-001	5306-00-625-4609	BOLT,RETAINER	1	NS
204-040-405-001	5306-00-625-4609	BOLT,RETAINER	1	OH
204-040-405-1	5306-00-625-4609	BOLT,RETAINER	1	SV
204-040-405-1	5306-00-625-4609	BOLT,RETAINER	1	SV
204-040-406-1	3110-00-690-8928	BEARING,ROLLER,CYLINDRICAL	1	NS
204-040-412-001	5310-00-703-8272	NUT,90 DEGREE GEAR	1	OH
204-040-412-001	5310-00-703-8272	NUT,90 DEGREE GEAR	2	SV
204-040-418-13	1615-00-739-4574	CASE ASSEMBLY,GEAR	2	SV
204-040-423-007	3130-00-176-1234	HOUSING,BEARING UNIT	8	NS
204-040-423-007	1615-XX-176-1234		8	NS
204-040-423-7	1615-00-176-1234	HOUSING,BEARING UNIT	2	NS

204-040-425-001	1615-00-972-2736	SLEEVE ASSEMBLY,TAI	1	AR
204-040-425-001	1615-00-972-2736	SLEEVE ASSEMBLY,TAI	1	NS
204-040-425-001	1615-00-972-2736	SLEEVE ASSEMBLY,TAI	1	NS
204-040-425-001	1615-00-972-2736	SLEEVE ASSEMBLY,TAI	1	OH
204-040-427-003	5365-00-981-3061	RING,EXTERNALLY THREADED	2	NS
204-040-427-003	5365-00-981-3061	RING,EXTERNALLY THREADED	1	OH
204-040-427-3	5365-00-981-3061	RING,EXTERNALLY THREADED	1	SV
204-040-430-001	1615-00-128-1663	HOUSING ASSY,NOZZLE	2	NS
204-040-430-001	1615-00-128-1663	HOUSING ASSY,NOZZLE	2	NS
204-040-430-001	1615-00-128-1663	HOUSING ASSY,NOZZLE	1	OH
204-040-500-010	3040-00-797-8573	GEARSHAFT,BEVEL	5	NS
204-040-500-010	3040-00-797-8573	GEARSHAFT,BEVEL	1	NS
204-040-500-9	3040-00-797-8576	GEARSHAFT,BEVEL	4	NS
204-040-502-011	1615-00-690-7602	CAP ASSY	5	NS
204-040-503-003	1560-00-682-5173	CAP,GEAR BOX	1	AR
204-040-508-001	6680-00-580-0724	INDICATOR,SIGHT,LIQUID	1	SV
204-040-508-009	1615-00-975-7131	DISK,INDICATOR,OIL	11	NS
204-040-513-001	1615-00-735-6560	CASE ASSEMBLY,TAIL	1	NE
204-040-513-1	1615-00-735-6560	CASE ASSEMBLY,TAIL	1	NS
204-040-600-009	3040-00-797-8576	GEARSHAFT,BEVEL	1	AR
204-040-600-011	1615-01-056-5365	HANGER ASSEMBLY,DRI	5	SV
204-040-600-011	1615-01-056-5365	HANGER ASSEMBLY,DRI	1	NS
204-040-600-11	1615-01-056-5365	HANGER ASSEMBLY,DRI	2	SV
204-040-600-9	1615-00-832-8951	HANGER ASSEMBLY,DRI	1	AR
204-040-602-005	3040-00-765-2408	SHAFT,SHOULDERED	10	NS
204-040-603-7	1615-00-791-6073	COUPLING,MALE SPHERICAL	1	NS
204-040-603-7	1615-00-791-6073	COUPLING,MALE SPHERICAL	1	SV
204-040-603-9	1615-00-523-9770	SPHERICAL DRIVE SHAFT,TAIL ROTOR DRIVE	1	SV
204-040-606-001	5365-00-691-2112	SPACER,RING	1	NS
204-040-607-1	5340-00-701-4143	RETAINER,HELICAL COMPRESSION SPRING	1	SV
204-040-610-1	1615-00-701-4144	PLATE ASSEMBLY,TAIL ROTOR DRIVE	1	NS
204-040-610-1	1615-00-701-4144	PLATE ASSEMBLY,TAIL ROTOR DRIVE	1	AR
204-040-610-1	1615-00-701-4144	PLATE ASSEMBLY,TAIL ROTOR DRIVE	2	NS
204-040-614-003	1615-00-765-2417	COUPLING,HANGER	4	SV
204-040-614-003	1615-00-765-2417	COUPLING,HANGER	6	SV
204-040-614-003	1615-00-765-2417	COUPLING,HANGER	6	SV
204-040-616-5	1615-00-448-9189	PLATE,RETAINING,TAIL ROTOR DRIVE	2	AR
204-040-617-017			1	SV
204-040-620-005	1615-00-019-0217	SHAFT ASSEMBLY,TAIL	4	OH
204-040-620-5	1615-00-019-0217	SHAFT ASSEMBLY,TAIL	1	NS
204-040-623-111	3110-01-030-4306	BEARING,BALL,ANNULAR	2	NE
204-040-680-1	1560-00-716-8593	HOUSING,DRIVESHAFT	3	NS
204-040-686-001	1615-00-605-5100	DRIVE SHAFT,HELICOPTER	20	NS
204-040-687-005	1615-00-069-3327	COUPLING,MAIN DRIVESHAFT	1	AR
204-040-687-5	1615-00-069-3327	COUPLING,MAIN DRIVESHAFT	5	NS
204-040-688-009	1615-00-731-8089	COUPLING,MAIN DRIVE	1	NS
204-040-690-001	5342-00-733-2553	RETAINER	12	NS
204-040-690-1	5342-00-733-2553	RETAINER	1	NS
204-040-700-001	1615-00-858-8394	PINION,MAIN INPUT,T	1	NS
204-040-700-100			1	OH
204-040-700-101	1615-00-858-8394	PINION,MAIN INPUT,T	2	NS
204-040-701-3	3020-00-898-6878	GEAR,BEVEL	1	OH
204-040-716-005	1615-00-761-2532	COUPLING SET	9	NS
204-040-722-001	4710-00-874-0864	TUBE ASSEMBLY,METAL	1	SV
204-040-723-001	4710-00-874-0865	TUBE ASSEMBLY,METAL	1	SV
204-040-723-1	4710-00-874-0865	TUBE ASSEMBLY,METAL	9	NS
204-040-725-1	3110-00-807-7833	ROLLER SET TRANSMIS	128	NS
204-040-731-091			1	NS
204-040-759-001	5330-00-051-3157	GASKET	11	NS
204-040-760-005	1650-00-003-5904	FILTER,FLUID	1	SV
204-040-761-001	1615-00-215-4301	JET LUBRICATOR,TRANSMISSION	1	RP
204-040-762-001	3020-00-019-0292	GEAR,SPUR	1	NE
204-040-762-1	3020-00-019-0292	GEAR,SPUR	1	OH
204-040-763-001	3020-00-019-0293	GEAR,SPUR	1	SV
204-040-763-1	3020-00-019-0293	GEAR,SPUR	1	OH
204-040-786-001	3110-00-755-1181	PLATE,RETAINING,BEARING	3	NS

204-040-786-001	3110-00-755-1181	PLATE,RETAINING,BEARING	5	NS
204-040-786-1	3110-00-755-1181	PLATE,RETAINING,BEARING	6	NS
204-040-786-1	3110-00-755-1181	PLATE,RETAINING,BEARING	2	SV
204-040-787-4267			6	NS
204-040-788-1	5310-00-916-2467	NUT,RETAINING	1	NS
204-040-789-005	3110-01-217-8346	RACE	8	SV
204-040-789-007	5365-01-020-2012	BUSHING,MACHINE THREAD	1	NS
204-040-789-5	3110-01-217-8346	RACE	8	SV
204-040-790-1	3120-00-915-6060	BUSHING,SLEEVE	4	SV
204-040-796-001	1680-00-872-1214	GEAR,SPUR AND ADAPTER ASSEMBLY	6	NS
204-040-796-1	1680-00-872-1214	GEAR,SPUR AND ADAPTER ASSEMBLY	6	NS
204-040-803-001	4920-00-945-8914	ADAPTER,SUPPORT,TUR	1	NS
204-040-811-001	3010-00-957-6866	CLAMP,COUPLING	1	SV
204-040-812-003	1615-00-979-8577	ADAPTER,DRIVESHAFT,	1	NS
204-040-812-003	1615-00-979-8577	ADAPTER,DRIVESHAFT,	5	NS
204-040-812-003	1615-00-979-8577	ADAPTER,DRIVESHAFT,	2	NS
204-040-812-3	1615-00-979-8577	ADAPTER,DRIVESHAFT,	3	NS
204-040-812-3	1615-00-979-8577	ADAPTER,DRIVESHAFT,	2	SV
204-040-812-3	1615-00-979-8577	ADAPTER,DRIVESHAFT,	1	NS
204-040-816-003	1615-00-570-9765	VALVE ASSEMBLY,OIL	2	RP
204-050-133-001	5360-00-675-3229	SPRING,HELICAL,COMPRESSION	6	NS
204-050-133-1	5360-00-675-3229	SPRING,HELICAL,COMPRESSION	1	NS
204-050-134-3	5315-00-670-7977	PIN	22	NS
204-050-149-1	1560-00-674-4216	STEP,SKID LANDING GEAR	1	NS
204-050-151-5	1560-00-898-0002	NUT ASSEMBLY,SKID GEAR	2	NS
204-050-154-001	5315-00-895-6797	PIN,CONNECTING	3	NS
204-050-155-5	1730-00-488-4998	RAM ASSEMBLY	1	AR
204-050-157-007	1730-00-691-0552	CRADLE,AXLE ROTATING	1	AR
204-050-160-001	1730-00-895-9343	ARM,GND HANDLING GEAR	4	SV
204-050-163-1C			1	NS
204-050-164-001	5315-00-895-6799	PIN,SUPPORT	6	NS
204-050-227-1	1630-00-070-7850	CAP,SKID TUBE	4	NS
204-050-241-4	1630-00-689-9997	SHOE,SKID TUBE ASSEMBLY,AIRCRAFT	2	NS
204-060-016-005			25	AR
204-060-045-1	4730-00-732-1691	ADAPTER,STRAIGHT,TUBE TO BOSS	1	NS
204-060-093-1	2995-00-738-8358	BRACKET,ENGINE ACCESSORY	2	NS
204-060-102-011	1560-00-409-9146	SUPPORT,STRUCTURAL COMPONENT,AIRCRAFT	3	NS
204-060-107-001	4710-00-739-4598	TUBE ASSEMBLY,METAL	6	NS
204-060-123-001	5306-00-670-8063	BOLT,EYE	56	NS
204-060-123-001	5306-00-670-8063	BOLT,EYE	4	NS
204-060-133-1-14821	1560-00-674-4219	BOLT,SHOULDER	1	NS
204-060-152-1	2995-00-775-7747	FITTING ASSEMBLY	10	NS
204-060-155-1	1560-00-731-8011	BIPOD ASSEMBLY,ENGINE MOUNT	5	SV
204-060-161-001	2995-00-731-7957	TRUNNION,LEFT HAND	9	NS
204-060-161-001	2925-00-731-7957	TRUNNION,LEFT HAND	5	NS
204-060-161-1	2995-00-731-7957	TRUNNION,LEFT HAND	1	NS
204-060-173-001	5365-00-738-8335	SHIM	10	NS
204-060-184-001	5330-00-847-1120	GASKET	4	NS
204-060-191-1	1560-00-875-7995	BRACKET,SUPPORT	24	NS
204-060-200-009	6115-00-927-7359	ADAPTER,GENERATOR TO AIR DUCT	1	AR
204-060-444-003	1660-00-872-1719	VALVE,BUTTERFLY	1	OH
204-060-448-003	2935-00-939-8428	TURBINE FAN,ENGINE COOLING	1	NS
204-060-448-3	4140-00-939-8428	TURBINE FAN,ENGINE COOLING	3	AR
204-060-468-001	1560-00-831-1452	SHROUD ASSEMBLY,COOLING	1	SV
204-060-503-001			1	NS
204-060-524-3	1560-00-625-0088	CONNECTOR,OIL SYSTEM	1	NS
204-060-541-003	5930-00-738-1640	SWITCH,PRESSURE	2	NS
204-060-567-001	4730-00-898-0007	ADAPTER,STRAIGHT,FLANGE TO TUBE	1	NS
204-060-591-101			1	AR
204-060-592-001	2935-00-066-0301	SCREEN ASSEMBLY,TURBINE FAN	2	NS
204-060-651-003	1560-00-625-0106	TUBE,FUEL,CROSSOVER	80	NS
204-060-712-001	1560-00-624-5167	SUPPORT ASSEMBLY,JACK SHAFT	7	NS
204-060-714-001			1	AR
204-060-752-005	5315-00-715-5433	PIN,STRAIGHT,HEADED	5	NS
204-060-762-001	1680-00-003-5906	ACTUATOR,ELECTRO-MECHANICAL,LINEAR	2	NS
204-060-762-001	1680-00-003-5906	ACTUATOR,ELECTRO-MECHANICAL,LINEAR	1	NS

204-060-762-001	1680-00-003-5906	ACTUATOR,ELECTRO-MECHANICAL,LINEAR	3	AR
204-060-762-001	1680-00-003-5906	ACTUATOR,ELECTRO-MECHANICAL,LINEAR	1	AR
204-060-762-1	2995-00-134-4683	ACTUATOR,LINEAR	1	SV
204-060-762-1	1680-00-990-3163	ACTUATOR,ELECTRO-MECHANICAL,LINEAR	1	NS
204-060-762-1	1680-00-990-3163	ACTUATOR,ELECTRO-MECHANICAL,LINEAR	1	RP
204-060-762-13			1	OH
204-060-765-007	2995-00-893-1216	LEVER ASSEMBLY	15	NS
204-060-786-1	1560-00-849-4193	BRACKET,DROOP COMPENSATOR	1	NS
204-060-786-1	1560-00-849-4193	BRACKET,DROOP COMPENSATOR	9	NS
204-060-786-1	1560-00-849-4193	BRACKET,DROOP COMPENSATOR	1	NS
204-060-787-001			1	NS
204-060-787-009	2995-00-927-3549	CAMBOX ASSY,DROOP C	1	NS
204-060-792-009	3040-00-718-6623	CONNECTING LINK,RIGID	2	SV
204-060-830-027	1560-00-676-6140	BUMPER,TRANSMISSION	22	NS
204-060-830-029	1615-00-676-6141	BUMPER,TRANSMISSION	37	NS
204-060-839-001	1560-00-701-0542	HANDLE,COWL LATCH	28	NS
204-060-845-003	1560-00-796-4229	BRACKET,COWL	9	NS
204-060-893-001	1560-00-758-3636	BRACKET,COWL HINGE	2	NS
204-060-937-001	1560-00-963-0964	BRACKET,COWL LATCH	15	NS
204-060-942-2	5340-00-757-8764	BRACKET,OUTER VENT	4	NS
204-060-943-001	1560-00-767-8025	FLAP HINGE,COWLING DOOR	1	NS
204-060-944-001	1560-00-977-7477	BRACKET,AFT FIREWALL	19	NS
204-061-100-001	3120-00-878-4389	BEARING,PLAIN,SELF-ALIGNING	3	NS
204-061-610-001	5930-00-736-4085	SWITCH,PRESSURE	6	NS
204-061-705-001	3040-00-898-0008	CAM,CONTROL	2	NS
204-061-716-007	3040-00-939-7531		1	NS
204-061-820-001	1560-00-072-8321	SUPPORT,ROLLER,COWL	7	NS
204-062-542-003	5930-00-868-8474	SWITCH,PRESSURE	1	NS
204-062-881-7	1560-00-151-4081	COWLING	5	NS
204-064-190-007			1	SV
204-070-085-1	5342-00-980-1850	BRACKET,LITTER TRACK PIN	5	AR
204-070-155-001	6680-00-841-0302	INDICATOR,ELECTRICAL TACHOMETER	1	AR
204-070-155-1	6680-01-125-0843	INDICATOR,ELECTRICAL TACHOMETER	1	AR
204-070-259-1	1560-00-886-3336	COVER,ACCESS	1	NS
204-070-259-1	1660-00-886-3336	COVER,ACCESS	4	NS
204-070-259-1B	1560-00-886-3336	COVER,ACCESS	1	NS
204-070-458-003	5360-00-055-2979	SPRING,HELICAL,EXTENSION	21	NS
204-070-522-003	1560-00-716-8602	BLANK ASSEMBLY,SOUNDPROOFING,BULKHEAD	2	NS
204-070-540-3	1560-00-010-0423	SUPPRESSOR,AIR DIS	1	NS
204-070-907-002	1680-00-946-6624	MOTOR,WINDSHIELD WIPER,ELECTRIC	1	RP
204-070-907-002	1680-00-946-6624	MOTOR,WINDSHIELD WIPER,ELECTRIC	4	NS
204-070-907-11	1680-01-113-2176	BLADE ASSEMBLY	6	NS
204-070-907-2	1680-00-946-6624	MOTOR,WINDSHIELD WIPER,ELECTRIC	1	NS
204-070-907-2	1680-00-946-6624	MOTOR,WINDSHIELD WIPER,ELECTRIC	1	AR
204-070-907-3	1680-00-781-4031	ARM,WINDSHIELD WIPER	1	SV
204-070-907-3	1680-00-781-4031	ARM,WINDSHIELD WIPER	3	AR
204-071-554-001	1560-00-987-5226	ADAPTER,GUN TURRET	4	NS
204-072-003-001	5315-00-780-9321	PIN,STRAIGHT,HEADED	4	NS
204-072-024-1	1560-00-921-8559	SUSPENSION ASSEMBLY,CARGO	1	AR
204-072-261-007	1660-00-409-8218	BLOWER UNIT,VENTILATION AND EXHAUST,HEAT E	1	SV
204-072-431-15	1660-00-932-1622	PARTS KIT,AIRCRAFT HEAT EXCHANGER	1	NS
204-072-819-001	1680-00-950-6938	STOP ASSEMBLY,QUICK	4	NS
204-072-905-003	1680-00-075-3388	RING,SUSPENSION ASS	8	NS
204-072-926-003	1680-00-067-8251	GUARD,HEAD PROTECTO	4	NS
204-072-926-003	1680-00-067-8251	GUARD,HEAD PROTECTO	2	AR
204-072-926-004	1680-00-879-0789	HEADGUARD ASSY,WINDSHIELD WIPER	1	NS
204-072-926-004	1680-00-879-0789	HEADGUARD ASSY,WINDSHIELD WIPER	4	NS
204-072-926-3	1680-00-067-8251	GUARD,HEAD PROTECTO	2	NS
204-075-134-001	1560-00-867-1172	BRACKET,BATTERY TIE DOWN	2	NS
204-075-134-001	1560-00-867-1172	BRACKET,BATTERY TIE DOWN	2	NS
204-075-254-015	1560-00-772-1877	KNOB ASSEMBLY,INDICATOR	10	NS
204-075-266-041	1560-00-994-5647	PANEL,BLANK	1	AR
204-075-363-003	5945-00-078-4792	RELAY,SOLID STATE	1	AR
204-075-365-009	5905-00-295-3808	RESISTOR,VARIABLE,WIRE WOUND,NONPRECISION	1	NS
204-075-372-001	5999-00-929-5781	CLAMP,ELECTRICAL	1	NS
204-075-399-001			1	AR

204-075-527-003	6220-00-828-4209	LIGHT,NAVIGATIONAL,AIRCRAFT	2	NS
204-075-541-015	5985-00-933-4561	SUPPORT,ANTENNA	1	NS
204-075-705			8	AR
204-075-705	1680-00-759-8274	PANEL,FAULT-FUNCTION INDICATOR,AIRCRAFT	1	NS
204-075-705-001			1	NS
204-075-705-019	1680-00-904-2442	PANEL,FAULT-FUNCTION INDICATOR,AIRCRAFT	7	NS
204-075-705-045	1680-00-850-4361	PANEL,FAULT-FUNCTION INDICATOR,AIRCRAFT	1	NS
204-075-705-047			1	RP
204-075-705-1			1	RP
204-075-705-1			2	NS
204-075-705-1	1680-00-904-2442	PANEL,FAULT-FUNCTION INDICATOR,AIRCRAFT	1	NS
204-075-705-101			1	NE
204-075-705-101			2	NE
204-075-705-27	1680-00-930-5101	PANEL,FAULT-FUNCTION INDICATOR,AIRCRAFT	1	RP
204-075-705-9	1680-00-850-4361	PANEL,FAULT-FUNCTION INDICATOR,AIRCRAFT	1	RP
204-075-861-001	6110-00-660-8708	BASE,VOLTAGE REGULATOR	1	NS
204-076-012-3	1650-00-930-5272	VALVE,HYDRAULIC ACC	1	NS
204-076-053-011	1650-00-014-2038	SERVOCYLINDER	1	NS
204-076-053-011	1650-00-014-2038	SERVOCYLINDER	11	NS
204-076-053-5	1650-00-944-8170	SERVOCYLINDER	2	NS
204-076-055-001	4810-01-022-3699	VALVE,HYDRAULIC,PRE	1	OH
204-076-055-001	4810-01-022-3699	VALVE,HYDRAULIC,PRE	1	NS
204-076-055-001	4810-01-022-3699	VALVE,HYDRAULIC,PRE	7	NS
204-076-055-001	4810-01-022-3699	VALVE,HYDRAULIC,PRE	6	AR
204-076-055-101	4810-01-127-0179	VALVE ASSY,HYDRAULI	4	NS
204-076-057-001	5930-01-077-6302	SWITCH,PRESSURE	1	NS
204-076-057-005	5930-00-401-7728		4	NS
204-076-057-7			1	NS
204-076-111-101			2	NS
204-076-162-001	1615-00-733-8320	BUSHING SET	6	NS
204-076-167-004	1615-00-733-8320		20	NS
204-076-171-001	5340-00-583-8622	BOOT,DUST AND MOISTURE SEAL	2	NS
204-076-171-001	5340-00-583-8622	BOOT,DUST AND MOISTURE SEAL	3	NS
204-076-175-001	4730-00-770-3483	BOLT,FLUID PASSAGE	2	NS
204-076-201-005	1650-00-944-1100	HOUSING,BEARING,SER	1	NS
204-076-267-005	9905-00-982-8822	PLATE,IDENTIFICATION	22	NS
204-076-268-1	5340-00-989-2983	CLEVIS,ROD END	2	NS
204-076-362-1	4710-00-872-1184	TUBE ASSEMBLY,METAL	8	NS
204-076-410-001	1680-00-923-2926	BOOT ASSEMBLY,SERVO	1	NS
204-078-026-4	1680-00-879-0789	HEADGUARD ASSY,WINDSHIELD WIPER	2	AR
204-101-746-1			1	SV
204-18	4330-00-963-2829	FILTER ELEMENT,FLUI	1	AR
204-40-606-001	5365-00-191-2112		5	NS
204-40-607-007			1	NS
204-706-268-001			14	NS
205-001-011-13	3040-00-964-5068	CONNECTING LINK,RIGID	1	AR
205-001-012-25	3040-00-877-2954	CONNECTING LINK,RIGID	1	NS
205-001-014-1	3040-00-964-5072	CONNECTING LINK,RIGID	2	AR
205-001-052-1			2	NS
205-001-053-009			7	NE
205-001-119-001	1680-00-133-6209	GRIP,CYCLIC STICK	3	NS
205-001-302-001	1560-00-944-7199	SUPPORT ASSEMBLY,LEVER CONTROL	11	SV
205-001-303-1	1560-00-996-0835	SUPPORT ASSEMBLY,COLLECTIVE CONTROL	7	NS
205-001-714-001	1560-00-918-3046	SUPPORT ASSEMBLY,BELLCRANK	1	NS
205-001-733-3			1	SV
205-001-745-1	1615-00-234-7299	COVER,TAIL ROTOR	1	NS
205-001-800-001	3120-00-964-6474		3	NS
205-001-902-005	1560-00-949-8231	LEVER,ELEVATOR CONTROL	1	NS
205-001-902-1	1560-00-963-1083	LEVER,ELEVATOR CONTROL	1	NS
205-001-906-001	1680-00-966-6103	BELL CRANK	4	NS
205-001-908-005			1	NS
205-001-908-1	1560-00-966-6104	IDLER ASSEMBLY,CONTROL	1	NS
205-001-909-005			1	NS
205-001-910-001	1560-00-966-6106	SUPPORT ASSEMBLY,CONTROL	1	NS
205-001-914-1	1560-00-966-7517	HORN,ELEVATOR	4	NS
205-001-914-101			1	AR

205-001-914-15			1	SV
205-001-915-001	1560-00-867-1213	IDLER ASSEMBLY	1	RP
205-001-918-001	1680-00-411-3130	SUPPORT ASSY	4	NS
205-001-921-001			1	NS
205-011-704-009	3040-00-134-8134	CONNECTING LINK,RIGID	5	NS
205-011-704-009	3040-00-134-8134	CONNECTING LINK,RIGID	12	NS
205-011-710-101	5310-01-211-9578	NUT,GRIP RETENTION	2	SV
205-011-710-101			42	NS
205-011-710-101			110	NS
205-012-710-001	3120-00-172-2761	BEARING,PLAIN,SELF-ALIGNING	4	NS
205-012-715-001	5365-00-172-4517	SHIM	1	NS
205-012-716-001	1615-00-172-4519	TRUNNION SET ASSEMBLY,TAIL ROTOR	1	NS
205-012-723-001	1615-00-023-3387	NUT ASSEMBLY,TAIL ROTOR	2	NS
205-030-007-297	1560-00-987-5131	DOOR,SKIN INSTALLAT	2	NS
205-030-028-045	1560-00-400-2750	DOOR,ACCESS,AIRCRAFT	1	NS
205-030-104-002	1560-00-119-1178	SUPPORT FITTING,LANDING GEAR	4	NS
205-030-104-002	1560-00-119-1178	SUPPORT FITTING,LANDING GEAR	1	NS
205-030-130-013	1560-00-438-6596	SEAL	2	NS
205-030-291-9	1560-00-834-6636	SUPPORT,STRUCTURAL COMPONENT,AIRCRAFT	2	SV
205-030-342-003			4	NS
205-030-342-003	1620-01-088-8494	SUPPORT,LANDING GEA	1	NS
205-030-407-323	1560-00-124-8064	SUPPORT ASSEMBLY,PYLON	1	NS
205-030-437-7	3120-00-967-1799	ROLLER,LINEAR-ROTARY MOTION	10	NS
205-030-476-3	5306-00-966-9359	BOLT,SHOULDER	4	NS
205-030-477-003	1560-00-488-7680	RETAINER ASSEMBLY	1	NS
205-030-505-003	5315-01-306-1870		1	NS
205-030-517-001	1560-00-966-9381	PIN,HINGED PANEL	3	NS
205-030-611-003	1560-00-114-1210	PAN ASSEMBLY,AIR VENT	3	SV
205-030-611-004	1560-00-813-9357	PAN ASSEMBLY,AIR VENT	1	NS
205-030-611-15	1560-00-986-9964	TUBE,PANEL ASSEMBLY	4	NS
205-030-614-27	1560-00-986-9962	PAD,PLATE ASSEMBLY	2	NS
205-030-615-094	1560-00-757-2904	SEAL,CABIN ROOF	2	NS
205-030-708-062	1560-00-124-1765	SUPPORT,BULKHEAD,FUSELAGE	4	NS
205-030-803-001	1560-00-923-2783	FITTING ASSEMBLY,SUPPORT	1	NS
205-030-814-17	1560-00-981-5074	COVER,ACCESS	1	NS
205-030-848-3	1560-00-011-4306		10	NS
205-030-919-037	1560-00-103-5401	BRACKET,PYLON SUPPORT	1	NS
205-030-939-033			4	NS
205-030-971-2	1560-00-169-0331	SUPPORT,LANDING GEAR	6	NS
205-031-152-1			2	NS
205-031-179-033	1560-00-442-1786	PANEL,STRUCTURAL,AIRCRAFT	4	NS
205-031-197-127	1560-00-179-4276	DECK ASSEMBLY,SERVICE	2	NS
205-031-197-127	1560-00-179-4276	DECK ASSEMBLY,SERVICE	1	NS
205-031-257-52	1560-00-442-1804	FLOOR,AIRCRAFT	9	NS
205-031-423-051	5330-00-069-9602		1	NS
205-031-423-25			15	NS
205-031-423-26	1680-01-093-8240	DOUBLER	2	NS
205-031-433-5C	5340-01-306-1902	BRACKET,ANGLE	1	NS
205-031-435-002	1560-00-967-3381	SUPPORT,ROLLER,CARGO DOOR	2	NS
205-031-436-001	1560-00-967-3380	SUPPORT,STRUCTURAL COMPONENT,AIRCRAFT	1	NS
205-031-481-031	5365-00-931-4801	SPACER,TAPERED	3	NS
205-031-501-001	5340-00-967-3379	HINGE,ACCESS DOOR	61	NS
205-031-501-002	5340-00-967-3378	HINGE,ACCESS DOOR	1	NS
205-031-502-001	5340-00-967-1787	HINGE,ACCESS DOOR	5	NS
205-031-502-002	5340-00-967-1788	HINGE,ACCESS DOOR	6	NS
205-031-511-001	1560-00-967-1794		4	SV
205-031-511-003	1560-00-141-6195		1	SV
205-031-516-002	5342-00-073-5437	HANDLE,RIGHT HAND	1	NS
205-031-516-002	5342-00-073-5437	HANDLE,RIGHT HAND	2	NS
205-031-668-007			1	NS
205-031-831-2	1560-00-498-1742	SUPPORT,TAIL BOOM	2	NS
205-031-831-2P			2	NS
205-031-831-4P			2	NS
205-032-669-83			1	NS
205-040-004-021	1615-01-014-6005	DRIVE ASSEMBLY,INPU	1	NS
205-040-100-003	3020-00-967-7661	GEAR,BEVEL	1	NS

205-040-100-003	3020-00-967-7661	GEAR,BEVEL	2	NS
205-040-100-3	1615-01-064-7501	WEIGHT,STABILIZER	4	NS
205-040-101-001	3020-00-967-7660	GEAR,SPUR	2	SV
205-040-102-001	3020-00-967-7668	GEAR,SPUR	1	NS
205-040-102-001	3020-00-967-7668	GEAR,SPUR	1	SV
205-040-106-001	3110-00-052-9135	BEARING,BALL,DUPLEX	5	NS
205-040-114-001	1560-00-992-6471	BRACKET,GENERATOR SUPPORT	12	NS
205-040-114-1	1560-00-992-6471	BRACKET,GENERATOR SUPPORT	2	NS
205-040-115-1	5330-01-388-8475	GASKET	1	NS
205-040-118-001	3130-00-070-7839	LINER,BEARING HOUSING	1	NS
205-040-120-001	5310-00-071-0907	WASHER,SHOULDERED	1	NS
205-040-121-001	5340-00-070-7838	COVER,ACCESS	1	NS
205-040-125-001	3040-00-070-7846	HOUSING,MECHANICAL DRIVE	1	NS
205-040-156-3	5340-00-106-2361	CLAMP,LOOP	2	NS
205-040-175-001	1615-00-068-6634	RETAINER,GREASE,DRIVE SHAFT	1	NS
205-040-175-1	1615-00-068-6634	RETAINER,GREASE,DRIVE SHAFT	14	SV
205-040-176-3	5340-00-141-0076	BOOT,DUST AND MOISTURE SEAL	2	NS
205-040-178-001	1615-00-076-1486	COUPLING,MAIN DRIVESHAFT	6	NS
205-040-178-001	1615-00-076-1486	COUPLING,MAIN DRIVESHAFT	3	NS
205-040-178-1	1615-00-076-1486	COUPLING,MAIN DRIVESHAFT	20	NS
205-040-186-1	5325-00-125-8887	RING,RETAINING	111	NS
205-040-229-001	3020-00-128-1634	GEAR,SPUR	5	NS
205-040-229-1	3020-00-128-1634	GEAR,SPUR	1	AR
205-040-229-1	3020-00-128-1634	GEAR,SPUR	2	NS
205-040-231-005S	1615-00-235-5472	RING GEAR ASSY	1	NS
205-040-232-001	3130-00-128-1620	LINER,BEARING HOUSING	1	NS
205-040-245-1	3110-00-133-3379	BEARING,BALL,DUPLEX	1	NS
205-040-246-003	3110-00-135-2603	BEARING,BALL,STACK	6	NS
205-040-2463	3110-00-135-2603	BEARING,BALL,STACK	12	NS
205-040-256-007	1615-00-128-1618	HOUSING,MAIN INPUT,	1	OH
205-040-256-7	1615-00-128-1618	HOUSING,MAIN INPUT,	1	SV
205-040-263-003	1615-00-134-3087	QUILL ASSY TRANSMIS	1	NS
205-040-307-1	5365-00-400-8362	SPACER SET	1	NS
205-050-152-32			16	AR
205-050-158-011	1730-00-066-0294	AXLE ASSEMBLY,GROUND HANDLING	3	SV
205-050-174-036			1	NS
205-060-020-001	2915-00-967-1738	SUPPORT,ENGINE ASSE	1	NS
205-060-105-1	1560-00-967-1751	TRIPOD ASSEMBLY,ENGINE	1	SV
205-060-105-1	1560-00-967-1751	TRIPOD ASSEMBLY,ENGINE	1	RP
205-060-110-1	1560-00-403-0594	FILLER,LAMINATED	24	NS
205-060-139-001	1560-00-072-4413	BRACKET,CLEVIS	1	NS
205-060-139-001	1560-00-072-4413	BRACKET,CLEVIS	7	NS
205-060-205-31	1560-01-129-1296	ANGLE,INDUCTION BAF	1	NS
205-060-235-1			2	NS
205-060-408-20	2925-00-076-7298	SHROUD ASSEMBLY,COO	1	NS
205-060-476-7	1560-00-073-3303	INLET DUCT ASSEMBLY	1	NS
205-060-539-3	1560-00-409-6615	CAP AND ADAPTER,OIL	1	NS
205-060-587-003			1	NS
205-060-606-003	2915-00-018-0012	PUMP,SUBMERGED,AIRCRAFT	1	SV
205-060-606-003	2915-00-018-0012	PUMP,SUBMERGED,AIRCRAFT	1	NS
205-060-606-3	2915-00-999-3705	PUMP,SUBMERGED,AIRCRAFT	2	NS
205-060-607-005	2915-00-012-8684	PUMP,SUBMERGED,AIRCRAFT	1	AR
205-060-607-005	2915-00-012-8684	PUMP,SUBMERGED,AIRCRAFT	5	NS
205-060-607-005	2915-00-012-8684	PUMP,SUBMERGED,AIRCRAFT	7	OH
205-060-607-005	2915-00-012-8684	PUMP,SUBMERGED,AIRCRAFT	1	AR
205-060-607-005	2915-00-012-8684	PUMP,SUBMERGED,AIRCRAFT	2	OH
205-060-607-005	2915-00-012-8684	PUMP,SUBMERGED,AIRCRAFT	2	NS
205-060-607-5	2915-00-921-5660	PUMP,SUBMERGED,AIRCRAFT	1	AR
205-060-607-5	2915-00-921-5660	PUMP,SUBMERGED,AIRCRAFT	18	OH
205-060-611-003	2915-00-003-5903	VALVE,FUEL,MANIFOLD	4	NS
205-060-612-003	2915-00-991-3255	VALVE,GATE,AIRCRAFT	1	NS
205-060-613-003	2915-00-968-6363	SWITCH,LIQUID LEVEL	3	NS
205-060-613-003	2915-00-968-6363	SWITCH,LIQUID LEVEL	4	NS
205-060-663-001	4730-00-249-3322	MANIFOLD,TANK VENT,FUEL	2	NS
205-060-666-001	4820-00-762-0058	VALVE,FLOW CONTROL	1	NS
205-060-696-001	1560-00-969-9220	TUBE ASSEMBLY,METAL	1	NS

205-060-702-1	3040-00-792-1494	CONNECTING LINK,RIGID	1	SV
205-060-715-001	1560-00-967-7577		3	NS
205-060-807-9	1560-00-844-7964	COWLING	45	NS
205-060-821-001	1560-00-963-1067	FITTING,COWL LATCH	1	NS
205-060-877-039	1560-00-420-0927	VENT,COWLING	5	NS
205-060-906-19	5330-00-961-4432	GASKET	25	NS
205-060-913-003	1560-00-992-6517	LATCH FITTING,AFT FIREWALL	1	NS
205-060-918-003	1560-00-992-6515	SUPPORT,STRUCTURAL COMPONENT,AIRCRAFT	1	NS
205-060-918-2	1560-00-992-6516	SUPPORT,STRUCTURAL COMPONENT,AIRCRAFT	2	NS
205-061-412-1	5340-00-182-6977	BRACKET,ANGLE	1	NS
205-061-537-001			2	NS
205-061-623-001	4820-00-758-9299	VALVE,CHECK	6	NS
205-061-631-3	1560-00-789-4947	CROSSOVER,FUEL,STANDARD	3	NS
205-061-633-007	6680-00-181-1955	INDICATOR,LIQUID QUANTITY	1	AR
205-061-633-009	6620-00-757-4860	TRANSMITTER,FORWARD	1	SV
205-061-633-011	6680-00-758-2819	TRANSMITTER,LIQUID QUANTITY	9	NE
205-061-633-017	6680-00-133-7911	TRANSMITTER,LIQUID QUANTITY	7	NE
205-061-633-017	6680-00-133-7911	TRANSMITTER,LIQUID QUANTITY	2	NS
205-061-633-019	6680-00-133-7912	TRANSMITTER,LIQUID QUANTITY	10	NE
205-061-634-1	4320-00-789-4969	PUMP,FUEL EJECTOR	3	NS
205-061-637-001	1560-00-789-4941	FITTING,FUEL TANK	8	NS
205-061-637-1	1560-00-789-4941	FITTING,FUEL TANK	19	NS
205-061-653-17			1	NS
205-061-660-001	1560-00-789-4940	SUPPORT,FUEL FLOAT	5	NS
205-061-660-1	1560-00-789-4940	SUPPORT,FUEL FLOAT	1	NS
205-061-680-001	1560-00-794-2576	SUMP ASSEMBLY,FUEL CELL	10	NS
205-061-680-1	1560-00-794-2576	SUMP ASSEMBLY,FUEL CELL	4	NE
205-062-636-1	1560-00-177-4172	COVER,ACCESS,AIRCRAFT	2	NS
205-062-636-1	1560-00-177-4172	COVER,ACCESS,AIRCRAFT	1	NS
205-062-640-001	1560-00-176-1273	SUMP ASSEMBLY,FUEL CELL	1	NS
205-062-650-001	4720-00-176-4605	HOSE ASSEMBLY,NONMETALLIC	1	NS
205-062-650-017	4720-00-182-8966	HOSE ASSEMBLY,NONMETALLIC	1	NS
205-062-650-021	4720-00-090-8911	HOSE ASSEMBLY,NONMETALLIC	1	NS
205-062-650-13	4720-00-176-4614	HOSE ASSEMBLY,NONMETALLIC	1	NS
205-062-650-23	4720-00-148-8602	HOSE ASSEMBLY,NONMETALLIC	1	NS
205-062-656-1	2915-00-134-4512	VALVE,FUEL PRESSURIZING AND DRAIN	1	NS
205-062-657-1	4820-00-134-4504	COCK,POPPET DRAIN	1	NS
205-062-657-1	4820-00-134-4504	COCK,POPPET DRAIN	5	NS
205-062-685-002	1560-00-176-1979	FITTING,OUTLET,FUEL	1	NS
205-063-602-001	4730-00-100-4341	COUPLING ASSEMBLY,QUICK DISCONNECT	1	NS
205-063-602-005	4730-00-100-4344	COUPLING ASSEMBLY,QUICK DISCONNECT	1	NS
205-063-602-3	4730-00-100-4342	COUPLING ASSEMBLY,QUICK DISCONNECT	1	NS
205-063-622-001	1560-01-066-2660	MANIFOLD,RELIEF VALVE	1	NS
205-070-106	1560-00-966-6110	BRACKET ASSEMBLY,INERTIA	46	NS
205-070-106	1560-00-966-6110	BRACKET ASSEMBLY,INERTIA	8	NS
205-070-234-1	1560-00-758-7305	ELBOW,TUBE	45	NS
205-070-234-1	1560-00-758-7305	ELBOW,TUBE	40	NS
205-070-284-003			1	SV
205-070-284-003			1	NS
205-070-424-005	1560-00-918-0729	DUCT ASSEMBLY,AIR DISTRIBUTION	1	NS
205-070-510-001	5360-00-052-4714	SPRING,HELICAL,EXTENSION	7	NS
205-070-515-007	1560-00-070-4603	HOOK ASSEMBLY,BLOOD BOTTLE	2	NS
205-070-612-054	5640-00-010-0393	BLANKET,SOUND ABSOR	1	NS
205-070-617-087			1	NE
205-070-729-005	1680-00-758-0184	BRACKET ASSEMBLY,LI	10	AR
205-070-764-001	1680-00-014-0717	FITTING,SEAT ASSEMBLY	1	NS
205-070-773-001	1560-00-758-5700	SUPPORT,LITTER GUIDE	1	AR
205-070-773-001	1560-00-758-5700	SUPPORT,LITTER GUIDE		NS
205-070-900-017			1	NS
205-070-923-005	5360-00-968-4689	SPRING,HELICAL,EXTENSION	11	NS
205-070-923-005	5360-00-968-4689	SPRING,HELICAL,EXTENSION	4	AR
205-070-944-001	3040-00-973-3347	CONNECTING LINK,RIGID	2	NS
205-070-944-007	1680-01-228-0053	LINKAGE ASSEMBLY	1	NS
205-070-994-001			1	NS
205-072-277-003	4820-00-931-2314	VALVE,REGULATING,TEMPERATURE	1	AR
205-072-277-5	1660-00-989-3807	VALVE,AIR TEMPERATU	1	NS

205-072-278-001			1	NS
205-072-408-1	5340-00-918-0722	BRACKET,MOUNTING	1	NS
205-072-424-001	4710-00-948-6527	TUBE ASSEMBLY,METAL	1	NS
205-072-712-003	5360-01-380-8893	SPRING,LEAF	1	NS
205-074-033-103	6340-01-153-8073	ALARM SET,PILOT WARNING	10	NS
205-075-084-001			2	NS
205-075-152-001			1	NS
205-075-158-001			1	AR
205-075-158-001			1	NS
205-075-205-7	6110-00-105-6255	PANEL ASSEMBLY,CONT	1	NS
205-075-251-001	6110-00-168-3807	PANEL ASSY,CONTROL	8	NS
205-075-251-001	6110-00-168-3807	PANEL ASSY,CONTROL	18	SV
205-075-251-1	6110-00-168-3807	PANEL ASSY,CONTROL	1	NS
205-075-382-001	5915-00-450-4678	FILTER,BAND PASS	1	AR
205-075-388-001	6340-00-179-2643	BOX,WARNING CONTROL	1	NS
205-075-388-001	6340-00-179-2643	BOX,WARNING CONTROL	1	NS
205-075-388-013	6340-01-135-5656	DETECTOR,RPM LIMIT	2	NS
205-075-388-11			3	NS
205-075-388-11			5	NS
205-075-402-009			1	NS
205-075-402-011			1	AR
205-075-402-5	5995-00-980-9474	CABLE ASSEMBLY,SPECIAL PURPOSE,ELECTRICAL	1	NS
205-075-642-001	5945-01-112-6313	RELAY,ELECTROMAGNETIC	1	AR
205-075-642-001	5945-01-112-6313	RELAY,ELECTROMAGNETIC	3	SV
205-075-788-1			1	AR
205-075-807-001			1	NS
205-076-029-9			4	AR
205-076-034-005	1650-00-457-9844	FILTER,FLUID	1	SV
205-076-034-005	1650-00-457-9844	FILTER,FLUID	5	NS
205-076-044-007	5930-00-253-8360	SWITCH,PRESSURE	2	AR
205-076-055-101			2	RP
205-076-056-107	1650-01-187-9395	CYLINDER ASSEMBLY,ACTUATING,LINEAR	1	RP
205-076-056-107	1650-01-187-9395	CYLINDER ASSEMBLY,ACTUATING,LINEAR	1	SV
205-076-099-007	1650-00-148-9077	CYLINDER ASSEMBLY,ACTUATING,LINEAR	1	RP
205-076-099-7	1650-00-148-9077	CYLINDER ASSEMBLY,ACTUATING,LINEAR	3	RP
205-076-099-7	1650-00-148-9077	CYLINDER ASSEMBLY,ACTUATING,LINEAR	3	NS
205-076-099-7	1650-00-148-9077	CYLINDER ASSEMBLY,ACTUATING,LINEAR	3	RP
205-076-116-001	4730-00-969-9211	CONNECTOR,MULTIPLE,FLUID PRESSURE LINE	2	NS
205-076-118-1	5340-00-012-4598	BRACKET,ANGLE	1	NS
205-076-118-1	5340-00-012-4598	BRACKET,ANGLE	2	NS
205-076-202-001	4710-00-987-1402	TUBE ASSEMBLY,METAL	1	NS
205-090-186-1			16	NS
205-090-186-1			8	SV
205-204-027-1	1560-XX-021-4658		1	NS
205-704-013-5	1560-00-078-9116	MODIFICATION KIT,AIRFRAME	2	NS
206-001-019-001	1560-00-127-3192		3	SV
206-001-020-113	3040-01-263-1022	CONNECTING LINK,RIGID	110	NS
206-001-061-003	5340-00-131-2588		9	SV
206-001-075-001	1680-00-128-7461	CYLINDER,FORCE GRAD	1	SV
206-001-075-1	1680-00-128-7461	CYLINDER,FORCE GRAD	6	NS
206-001-075-1	1680-00-128-7461	CYLINDER,FORCE GRAD	1	SV
206-001-076-001	1680-00-126-4350	FORCE GRADIENT ASSY	1	NS
206-001-107-13	1680-00-126-4340	GRIP,COLLECTIVE STICK	1	SV
206-001-121-001	3120-00-130-5862	BEARING,JACKSHAFT,C	1	SV
206-001-155-001	1680-00-128-7487	LEVER ASSEMBLY,COLLECTIVE PITCH	6	SV
206-001-174-003	1680-00-125-8871		1	NS
206-001-174-3	1680-00-125-8871	JACKSHAFT ASSY,CONT	4	SV
206-001-188-1	3130-00-182-8629	BEARING UNIT,BALL	1	NS
206-001-189-3	3040-01-241-7457	TUBE ASSY,CONNECTIN	3	NS
206-001-194-1	3040-01-007-5514	CONNECTING LINK,RIGID	1	AR
206-001-346-003			1	SV
206-001-360-5	1680-00-128-7370	PIVOT SUPPORT,CONTR	1	NS
206-001-363-005			1	SV
206-001-363-009	1680-00-128-7375		1	SV
206-001-364-001	1680-00-135-0515	TRUNNION AND BEARIN	6	SV
206-001-376-001	1680-00-128-7369		1	SV

206-001-522-1	1650-00-128-7440	BELL CRANK	1	SV
206-001-523-001	3040-00-133-1228	BRACKET,EYE,ROTATING SHAFT	3	NS
206-001-525-001	3040-00-133-3375		1	OH
206-001-528-001	1615-00-125-4148		2	SV
206-001-529-001	3040-00-133-3374	BRACKET,EYE,ROTATING SHAFT	4	NS
206-001-544-006	1560-00-133-6098	SUPPORT ASSY,BELL C	1	NS
206-001-544-5	1560-00-133-6101	SUPPORT,BELL CRANK	8	NS
206-001-554-001			1	NS
206-001-555-001			1	SV
206-001-701-1	3040-00-179-6816	CONNECTING LINK,RIGID	2	NS
206-001-703-002	1680-00-178-8465	PEDAL,CONTROL	3	NS
206-001-703-2	1680-00-178-8465	PEDAL,CONTROL	1	NS
206-001-705-5	1680-00-454-8967	BELL CRANK	2	NS
206-001-706-003	5340-00-176-0918	CLEVIS,ROD END	2	SV
206-010-002-121			1	AR
206-010-101-9	1615-00-120-0480	YOKE ASSY,MAIN ROTO	1	AR
206-010-102-013	1615-01-098-7496	GRIP ASSY,MAIN ROTO	2	AR
206-010-118-1	5365-00-178-7989	SPACER,SLEEVE	1	SV
206-010-121-005	1615-00-125-4076	RETAINER,SPRING,BLA	8	OH
206-010-123-003	5315-00-091-9358	PIN,STRAIGHT,HEADLESS	2	OH
206-010-152-3	5306-00-131-7305	BOLT,INTERNALLY RELIEVED BODY	1	SV
206-010-155-7	1615-00-121-6394		2	NS
206-010-169-003	5306-00-130-7958	BOLT,SPECIAL	2	OH
206-010-222-009	3120-00-536-2909	BUSHING,SLEEVE	1	NS
206-010-222-13	3120-01-026-4722	BUSHING,SLEEVE	26	NS
206-010-222-175			5	NS
206-010-421-003	3120-00-133-1239		3	NS
206-010-421-011	3120-00-133-4133		1	NS
206-010-453-11			2	SV
206-010-459-001	3120-00-179-7325	BEARING,SLEEVE	1	NS
206-010-462-001			3	NS
206-010-463-005	5365-00-178-2997		2	NS
206-010-470-01			1	NS
206-010-712-5			1	NS
206-010-742-1	1615-00-125-4090	STOP,STATIC,TAIL ROTOR	2	NS
206-010-750-109	1615-01-137-8136	BLADE,ROTARY RUDDER	3	NS
206-011-005-1	1615-00-121-6577	COLLAR,SWASHPLATE D	2	RP
206-011-100-131	1615-01-092-6746	HUB ASSEMBLY,MAIN R	2	AR
206-011-102-117			4	OH
206-011-104-005	1615-00-369-9458		2	SV
206-011-104-009			3	OH
206-011-104-5	1615-00-369-9458	PITCH HORN ASSEMBLY	3	NS
206-011-106-1	1615-00-126-4072	SHIELD,HUB,MAIN ROTOR	1	NS
206-011-107-1	1615-00-125-4130	SIGHT GLASS,GRIP,MA	1	SV
206-011-109-001	1615-01-264-8219	STOP,STATIC	1	NS
206-011-113-103			2	SV
206-011-113-103	1615-01-086-0153	TRUNNION,MAIN ROTOR	1	NS
206-011-121-103			2	OH
206-011-129-003	2590-01-107-6073	RETAINER,OIL SEAL	4	NS
206-011-151-1	1615-00-830-9736	BOLT ASSEMBLY,MAIN ROTOR	1	NS
206-011-159-101			2	NS
206-011-160-101	1615-01-264-8219	STOP,STATIC	3	NS
206-011-716-001	1615-00-482-2539	BALANCE WHEEL,ROTOR	4	NS
206-011-728-105	3130-01-226-4683	HOUSING,BEARING UNIT	5	NS
206-011-803-5	1615-00-121-6392	TRUNNION ASSY,TAIL ROTOR	1	NS
206-011-806-001	1615-00-125-4087	BUSHING ASSEMBLY,THRUST	1	NS
206-011-808-01	5310-00-192-0401	WASHER,FLAT	12	NS
206-01-453-5	1615-00-121-6454	RING,SWASHPLATE	1	SV
206-022-100-01	1560-00-129-6167	SUPPORT,STRUCTURAL COMPONENT,AIRCRAFT	1	NS
206-022-113-037	5340-00-178-1453	BUMPER,RUBBER	1	NS
206-031-120-19	1560-00-602-5768		3	NS
206-031-144-1			1	NS
206-031-353-3			1	NS
206-031-369-2	1560-01-005-1689	FITTING,STEP	3	NS
206-031-565-001	1680-00-135-0510	RECEPTACLE,DOOR HANDLE	8	NS
206-031-574-052	1680-00-168-5622	HANDLE,DOOR	2	NS

206-031-574-19	1560-00-551-3046	ROD,JETTISON MECHANISM,DOOR	1	NS
206-031-574-19	1560-00-551-3046	ROD,JETTISON MECHANISM,DOOR	1	NS
206-032-106-075			1	AR
206-032-119-3	1560-00-415-6392	INSERT,SUPPORT,FUEL	3	NS
206-032-124-21	1560-00-133-6957	SUPPORT,NOSE,AIRCRAFT	1	AR
206-032-124-55			27	NS
206-032-124-80	1560-00-173-2324	RETAINER,SKIN,AIRCRAFT	3	SV
206-032-312-103			1	NS
206-032-488-9	1560-01-032-3841	RETAINER,WINDSHIELD	69	NS
206-032-593-125	1560-01-214-9152	BRACKET	2	NS
206-032-593-125	1560-01-214-9152	BRACKET	1	NS
206-033-510-001			2	NS
206-033-519-003			4	NS
206-040-036-5	3110-01-033-8647	BEARING,BALL,ANNULAR	1	OH
206-040-038-1	3110-00-179-7324	BEARING,BALL,ANNULAR	31	NS
206-040-047-001	5310-00-131-2655	NUT,SPECIAL	1	SV
206-040-062-3	3110-00-125-8836	PLATE,RETAINING,BEARING	1	NS
206-040-078-101			1	NS
206-040-110-003	2840-00-563-7134	SHAFT,TURBINE,AIRCRAFT GAS TURBINE ENGINE	1	NS
206-040-113-3	1615-00-454-8837	PLATE,LOCKING,NUT,TRANSMISSION	1	AR
206-040-120-1	3040-00-121-6561	GEARSHAFT,MULTIPLE GEARS	1	NS
206-040-120-1	3040-00-121-6561	GEARSHAFT,MULTIPLE GEARS	5	NS
206-040-124-001	3020-00-122-5149	GEAR,INTERNAL	1	NS
206-040-129-005			1	SV
206-040-130-001	3110-00-179-7299	BEARING,BALL,STACK	4	NS
206-040-130-001	3110-00-179-7299	BEARING,BALL,STACK	29	NS
206-040-133-001			17	NS
206-040-151-013	1615-00-181-5567	HOUSING ASSY,MECHAN	1	NS
206-040-151-13	1615-00-181-5567	HOUSING ASSY,MECHAN	1	SV
206-040-198-009	1615-01-033-8099	NOZZLE ASSEMBLY	232	NS
206-040-198-9	1615-01-033-8099	NOZZLE ASSEMBLY	232	NS
206-040-220-003			1	NS
206-040-236-009	3040-01-038-2963	HOUSING,MECHANICAL DRIVE	2	NS
206-040-238-5			1	NS
206-040-245-001	1615-00-124-1637	FITTING,FREEWHEELING	2	NS
206-040-247-001			33	NS
206-040-304-103	1615-01-214-0212	DRIVE SHAFT-SEG	1	NS
206-040-319-9	1615-01-016-5901	COLLAR,BEARING,TAIL	69	NS
206-040-330-3	1615-00-121-6565	SHAFT ASSY,TAIL ROT	1	AR
206-040-365-109	1615-01-214-9163	DRIVESHAFT ASSY,TAI	1	NS
206-040-369-001	1615-01-214-9166		1	NS
206-040-400-9	1615-00-432-2492	GEARBOX,ROTARY RUDD	2	NS
206-040-408-001	3110-00-179-7397	BEARING,BALL,DUPLEX	83	NS
206-040-409-001	3110-00-179-7399	BEARING,ROLLER,CYLINDRICAL	1	NS
206040411-1	3110-00-179-7398	BEARING,ROLLER,CYLINDRICAL	5	AR
206040411-1	3110-00-179-7398	BEARING,ROLLER,CYLINDRICAL	5	NE
206-040-614-3			1	SV
206-040-813-001			1	NS
206-050-128-001	3040-00-136-2345	SHOE,SKID	5	AR
206-050-129-001	1630-00-125-8882	SHOE,SKID	5	AR
206-06-001-746-9			1	NS
206-060-200-009			2	NS
206-060-629-005			1	SV
206-060-837-001			1	NS
206-061-104-003	2995-00-130-6040	FITTING,ENGINE MOUN	3	AR
206-061-104-3	2995-00-130-6040	FITTING,ENGINE MOUN	18	NS
206-061-432-005			1	AR
206-061-544-1	2935-01-033-8217	DUCT,OIL COOLER	1	NS
206-061-544-1	2935-01-033-8217	DUCT,OIL COOLER	1	NS
206-062-101-1	4560-00-126-9161	LEG,ENGINE MOUNT,FO	2	NS
206-062-224-003	2840-00-157-0992	SEGMENT,AIR DUCT	1	NS
206-062-510-1	4710-21-860-2386		1	AR
206-062-616-003	1560-00-134-5194	SUPPORT,FUEL VALVE	2	NS
206-062-617-005	1680-00-133-1220	LEVER ASSY,SHUT&OFF	1	NS
206-062-617-005	1680-00-133-1220	LEVER ASSY,SHUT&OFF	12	NS
206-062-648-1	1560-00-152-3461	RETAINER,FILLER CAP	6	AR

206-062-687-101	2915-01-124-5222	PUMP,SUBMERGED,AIRCRAFT	6	AR
206-062-802-019	1560-01-005-3930		18	NS
206-062-802-077	1560-00-168-1687	BRACE ASSEMBLY,ARMOR	10	NS
206-062-802-73	1560-00-175-6640	BRACE ASSEMBLY,ARMOR	22	SV
206-062-802-73	1560-00-175-6640	BRACE ASSEMBLY,ARMOR	17	NS
206-062-802-73	1560-00-175-6640	BRACE ASSEMBLY,ARMOR	8	SV
206-062-807-001	1560-00-462-0439	ARMOR,SUPPLEMENTAL,SMALL ARMS-FRAGMENT/	7	NS
206-062-807-1	1560-00-462-0439	ARMOR,SUPPLEMENTAL,SMALL ARMS-FRAGMENT/	1	AR
206-062-832-001	5340-00-165-4032	BOOT,DUST AND MOISTURE SEAL	2	NS
206-064-109-103			9	NS
206-070-155-001			1	RP
206-070-155-01			1	AR
206-070-211-1			3	SV
206-070-265-005	6680-00-150-6525	INDICATOR,ELECTRICAL TACHOMETER	2	NS
206-070-368-019	1560-00-462-0442	DUCT,AIR OUTLET	1	NS
206-070-368-5	1560-00-128-7528	DUCT ASSY,AIR	1	NS
206-070-887-005	1680-00-128-7489	CASE,MAP AND DATA	1	NS
206-070-891-9	1560-00-127-5755	INSULATION BLANKET	2	SV
206-070-894-5	1560-00-176-2104	BLANKET ASSY,ACOUST	6	NS
206-071-203-001	1560-00-127-5759	FITTING ASSY,SIGHT	6	SV
206-071-206-3	1560-00-133-7369	STOP,DEPRESSION LIM	6	NS
206-071-207-001	1560-00-192-6271		6	NS
206-071-213-1	1560-00-129-6288	SEAL ASSY,DOOR	11	SV
206-071-213-3	1560-00-252-6114	SEAL ASSY,DOOR	7	NS
206-073-725-4	1560-01-032-3875	DUCT ASSEMBLY,AIR CONDITIONING-HEATING,AIR	1	SV
206-073-726-001			1	NS
206-073-726-1	1560-01-032-3873	DUCT ASSEMBLY,AIR CONDITIONING-HEATING,AIR	1	NS
206-073-727-001			1	NS
206-073-727-1	1560-01-032-3868	DUCT ASSEMBLY,AIR CONDITIONING-HEATING,AIR	1	SV
206-073-729-1	1560-01-032-3875	DUCT ASSEMBLY,AIR CONDITIONING-HEATING,AIR	1	SV
206-073-731-001	1660-01-031-6981	VALVE,FLAPPER	1	NS
206-073-731-001	1660-01-031-6981	VALVE,FLAPPER	1	NS
206-073-731-1	1660-01-031-6981	VALVE,FLAPPER	1	NS
206-073-731-1	1660-01-031-6981	VALVE,FLAPPER	2	NS
206-073-731-1	1660-01-031-6981	VALVE,FLAPPER	1	NS
206-073-731-1	1660-01-031-6981	VALVE,FLAPPER	30	NS
206-073-900-003	4320-00-451-5908	PUMP UNIT,CENTRIFUGAL	1	SV
206-075-365-006			2	NS
206-075-491-9	1680-00-152-3672	PANEL,INDICATING,LIGHT TRANSMITTING	4	NS
206-075-523-2RH	5985-00-134-5393	ANTENNA	5	SV
206-075-523-2RH	5985-00-134-5393	ANTENNA	10	SV
206-075-619-101	5930-01-078-5821	SWITCH,TOGGLE	327	NS
206-075-619-101			73	NS
206-075-687-101			1	NS
206-075-705-003	6695-01-160-6690	INDICATOR,ENGINE OI	2	AR
206076 368-1	1650-00-129-6122	HOUSING,RESERVOIR,H	5	NS
206-076-055-001			1	SV
206-076-055-001	4810-01-022-3699	VALVE,HYDRAULIC,PRE	4	NS
206-076-055-1	4810-01-022-3099		5	NS
206-076-368-1	1650-XX-129-6122		8	NS
206-076-372-1	1560-00-128-1703	SUPPORT ASSY,HYDRAULIC	1	NS
206-375-011-101	6620-01-299-1811	INDICATOR,ELECTRICAL TACHOMETER	1	AR
206-631-593-1			3	NS
206-961-452-005	1560-01-320-5393	FRAME,WINDOW,VEHICULAR	1	NS
206-961-452-6	1680-01-172-4972	FRAME ASSY,R H	1	NS
206-961-452-6	3020-00-083-3872	DISC ASSEMBLY,DAMPE	19	NS
2070326-4220			3	SV
2079-04331-04331-701-10	3110-00-807-7833	ROLLER SET TRANSMIS	32	NS
2-080-000-13			1	NS
2-080-350-07	2840-00-779-3612	COVER ASSY,GEARBOX	1	OH
209-001-145-13	1560-00-499-9560	BOOT ASSEMBLY	2	NS
209-001-764-001	1680-00-453-6143	BELL CRANK	1	AR
209-001-780-1	3020-00-134-8042	GUARD,CHAIN	20	NS
209-010-464-1	1615-00-482-1068	EXTENSION,PYLON ASS	8	NS
209-010-464-1	1615-00-482-1068	EXTENSION,PYLON ASS	7	NS
209-011-720-001	3040-00-252-8421	HOUSING,MECHANICAL DRIVE	1	OH

209-011-720-001	3040-00-252-8421	HOUSING,MECHANICAL DRIVE	1	AR
209-030-245-1	1680-00-223-9868	FITTING,JACK	1	AR
209-030-302-003	1620-00-779-3420	SUPPORT,LANDING GEA	1	NS
209-030-357-001	1560-00-221-5691	LINK ASSEMBLY,LIFT TRANSMISSION	5	AR
209-030-357-001	1560-00-221-5691	LINK ASSEMBLY,LIFT TRANSMISSION	8	NS
209-032-197-1	1560-01-044-6816	SUPPORT,CONTROL-ROTOR BRAKE	14	NS
209-040-069-001	1615-01-048-5700	QUILL ASSEMBLY GEN	1	OH
209-040-069-1	1615-01-048-5700	QUILL ASSEMBLY GEN	9	OH
209-040-104-1	1615-01-045-8769	SUPPORT,SUN GEAR,TRANSMISSION	484	RP
209-040-400-13	1615-00-176-1233	QUILL ASSY,GEARBOX,	1	NS
209-040-400-7			1	OH
209-060-129-002	1560-00-842-6232	FITTING,ENGINE DECK	2	NS
209-060-301-19	2840-00-131-6410	DUCT,EXHAUST,TURBINE ENGINE	1	NS
209-060-304-001	2995-00-878-3108	SHIELD ASSEMBLY	3	NS
209-060-521-001	1560-00-973-1254		1	RP
209-060-651-009	1560-00-007-8506	CAP AND RECEIVER ASSEMBLY,REFUELING SYSTE	6	NS
209-060-651-009	1560-00-007-8506	CAP AND RECEIVER ASSEMBLY,REFUELING SYSTE	1	AR
209-060-651-011	1560-01-095-4337	RECEIVER,REFUELING	1	AR
209-060-651-1	4930-01-314-8684	NOZZLE,FUEL AND OIL SERVICING	1	AR
209-060-651-9	1560-00-007-8506	CAP AND RECEIVER ASSEMBLY,REFUELING SYSTE	1	SV
209-060-655-005	4820-00-181-9230	COCK,POPPET DRAIN	1	AR
209-060-692-001	4730-00-591-0715	COUPLING ASSEMBLY,SELF-SEALING	1	NS
209-060-692-001	4730-00-591-0715	COUPLING ASSEMBLY,SELF-SEALING	1	AR
209-060-692-001	4730-00-591-0715	COUPLING ASSEMBLY,SELF-SEALING	1	NS
209-060-694-3	1560-01-068-5318	RECEIVER,REFUELING	2	NS
209-060-694-5	1560-01-068-5326	RECEIVER,CLOSED CIRCUIT REFUELING	2	RP
209-062-601-003	2915-01-047-3868	VALVE,GATE,AIRCRAFT	1	NS
209-062-761-001	5945-00-400-8297	SOLENOID,ELECTRICAL	1	AR
209-062-761-001	5945-00-400-8297	SOLENOID,ELECTRICAL	3	AR
209-062-818-5	5340-00-528-1582	HINGE ASSEMBLY	1	NS
209-070-182-001			1	AR
209-070-278-001	6610-01-098-5723		1	OH
209-070-568-001	1660-00-552-3812		4	NS
209-071-042-46	1560-00-179-6561	FAIRING,AIRCRAFT	1	RP
209-071-043-34	1560-00-051-5624		1	SV
209-071-048-001			2	AR
209-072-419-001	1660-00-183-0936	VALVE,LINEAR,DIRECTIONAL CONTROL	1	RP
209-074-033-103			3	NS
209-075-202-1	6220-00-936-8474	PANEL,INDICATING,LIGHT TRANSMITTING	2	NS
209-075-228-1	6110-00-454-8843	REGULATOR,VOLTAGE	2	AR
209-075-325-071			1	NS
209-075-651-3	6685-01-025-8229	INDICATOR,TEMPERATURE,THERMOCOUPLE	9	NS
209-075-768-3	1680-01-251-6023	CONTROL,GUNNERS,ARMAMENT	1	AR
209-076-374-1	5360-00-403-7673	SPRING,HELICAL,COMPRESSION	12	NS
209-961-406-001			16	AR
2-100-050-11	2840-00-894-0496	VANE SEGMENT,FAN,AIRCRAFT GAS TURBINE ENG	8	NS
21-010-15-5-12-5	3120-00-995-3064	BUSHING,SLEEVE	2	NS
2104-24	5330-00-796-4971	PACKING WITH RETAINER	50	NS
21161-035B			41	NS
212-001-171-001	1680-00-410-3241	GRIP,UPPER THROTTLE	3	NS
212-001-199-007			1	NS
212-001-210-1	3040-01-008-8110	BELL CRANK	1	NS
212-010-306-1			29	NS
212-010-403-5	1615-00-471-5918	LEVER,MAIN ROTOR	3	NE
212-010-404-005	3040-00-497-3445	CONNECTING LINK,RIGID	1	SV
212-010-707-001	1615-00-254-2192	CROSSHEAD ASSEMBLY	1	SV
212-010-714-003	5310-00-410-3430	WASHER,FLAT	1	NS
212-010-736-001			1	NS
212-010-738-001	1615-00-254-2206	TRUNION SET,ROTOR	1	NS
212-010-738-005			2	NS
212-010-739-007	1615-00-172-4521	SUPPORT,COUNTER WEIGHT,TAIL ROTOR	1	OH
212-010-772-001	1635-00-346-7661	LOCK,CROSSHEAD RETAINER TAIL ROTOR	20	NS
212-011-704-105	3040-01-252-5865	SPIDER,UNIVERSAL JOINT	2	NS
212-011-713-001	5355-01-252-5852	STOP,DIAL	3	NS
212-011-716-001	2840-01-252-7603	HOUSING ASSY	5	NS
212-030-096-001	5306-00-470-8740	BOLT,SPECIAL	2	NS

212-030-181-1	1560-00-409-1601	PAN ASSY	8	NS
212-030-286-2	1560-00-439-3712	FITTING,CYCLIC CONT	1	NS
212-040-184-001	4320-00-150-0309	PUMP,ROTARY	1	AR
212-040-189-003	1615-01-130-8857	SLEEVE,OIL SEAL RETAINING	1	NS
212-040-201-001	3020-00-460-3280	GEAR,SPUR	1	NS
212-040-237-003	4810-01-502-4149		1	NS
212-040-237-003	4810-01-502-4149		3	NS
212-040-356-017			1	NS
212-040-363-1	1615-00-486-0528	QUILL ASSEMBLY	1	NS
212-040-364-1	1615-00-235-5496		18	NS
212-040-364-1	1615-00-235-5496		2	NS
212-040-451-001			16	AR
212-040-451-001			1	NS
212-040-452-001	1615-00-439-5599	SLEEVE,OUTPUT,GEARBOX	1	OH
212-040-455-1	3110-00-450-7353	BEARING,ROLLER,CYLINDRICAL	1	SV
212-040-456-1	3110-00-460-2963	BEARING,BALL,DUPLEX	2	SV
212-040-456-1	3110-00-460-2963	BEARING,BALL,DUPLEX	1	SV
212-040-458-001	1615-00-460-2912	NUT,TAIL ROTOR DRIVE	1	OH
212-040-459-001	1615-00-439-5576	SLEEVE,INPUT,GEARBO	1	OH
212-040-459-001	1615-00-439-5576	SLEEVE,INPUT,GEARBO	13	NS
212-040-466-1	3110-00-450-7354	BEARING,ROLLER,CYLINDRICAL	1	SV
212-040-468-001	1615-00-240-6467	CASE ASSY	1	OH
212-040-470-001	5365-00-460-4872	RING,EXTERNALLY THREADED	6	NS
212-040-470-1	5365-00-460-4872	RING,EXTERNALLY THREADED	12	NS
212-040-500-004	3040-00-438-6323	GEARSHAFT,BEVEL	3	NS
212-040-500-005	3040-00-471-5794	GEARSHAFT,BEVEL	2	NS
212-040-500-5	3040-00-471-5794	GEARSHAFT,BEVEL	1	NS
212-040-630-005	1615-01-305-6418	ADAPTER,DRIVESHAFT	1	NS
212-040-631-001	4730-00-411-0864	PACKING NUT	4	NS
212-050-206-003			3	NE
212-052-709-001			1	NS
212-060-785-003	3040-01-337-2283	CAM,CONTROL	6	NS
212-060-825-1	1560-00-471-4481	FITTING,COWL LATCH	6	NS
212-060-827-001	1560-00-451-6482	LATCH ASSEMBLY	1	NS
212-061-207-046			2	NS
212-061-902-11	5940-00-168-3378	SPLICE SET,QUICK DISCONNECT	25	NS
212-061-902-111	5330-00-463-1396	SEAL,SPECIAL	81	NE
212-061-902-113	5330-00-422-2872	SEAL,ASSY SPECIAL	2	NS
212-062-504-001			1	NS
212-062-712-001			2	NS
212-062-714-001			1	NS
212-070-242-011			1	NS
212-070-428-001	1580-00-129-6272	ROD ASSY,SIGHT CONTROL	4	NS
212-073-532-001			1	NS
212-073-541-001			1	NS
212-075-062-017			1	NS
212-075-186-003			1	NS
212-076-006-005	4810-00-007-3455		1	SV
212-076-006-007	4810-01-484-0297	VALVE,REGULATING,FLUID PRESSURE	1	SV
212-076-010-1	4320-00-479-6068	PUMP,AXIAL PISTONS	1	NS
212-076-110-003	1650-01-132-5837	BODY,ACCUMULATOR ASSEMBLY	2	NS
212-076-116-101	5340-01-333-8736	BRACKET,MOUNTING	1	NS
212-101-707-00			3	NS
212-340-100-103	5330-01-467-4419	SEAL,PLAIN ENCASED	6	NS
212-540-688-003			1	NS
214-001-301-001	1680-01-017-5207	SUPPORT,CYCLIC CONTROLS,AIRCRAFT	2	NS
214-001-346-007	1680-01-024-9407	GRIP ASSEMBLY,CYCLI	1	NS
214-010-162-003			3	NS
214-010-170-1	5365-01-047-7174	SPACER,GRIP ASSEMBLY	2	RP
214-010-257-101			2	NS
214-010-257-101	5340-01-286-2028	CLEVIS,ROD END	4	NS
214-010-408-5	1615-00-535-0063	LINK,DRIVE,ROTOR	1	NS
214-010-435-003			2	NS
214-010-480-1	3110-01-046-2090	BEARING,ROLLER,NEEDLE	5	NS
214-010-536-105			1	NS
214-010-536-109	1615-01-256-8182	DRIVE LINK ASSEMBLY	2	NS

214-010-538-101			5	NS
214-010-701-3	1615-01-139-3643		1	RP
214-010-714-001			1	NS
214-010-833-001			1	NS
214-040-067-3			1	NS
214-040-125-5	3110-01-047-7005	BEARING,BALL,DUPLEX	1	NS
214-040-492-105			2	NS
214-040-599-139			1	NS
214-040-600-005			1	NS
214-040-600-5			2	NS
214-040-604-101			1	NS
214-040-606-001			6	NS
214-040-629-101			4	NS
214-040-656-101	1615-01-256-7476	COUPLING,MALE,MAIN GEAR	2	NS
214-073-912-001			1	NS
214-073-917-105	4140-01-256-7680	BLOWER,AIR BARRIER	1	RP
214-075-221-003			1	AR
214-076-033-1	4320-01-039-3658	PUMP,HYDRAULIC	1	NS
2-141-338-04	2840-01-107-7642	SUPPORT,TURBINE NOZ	1	NS
2-141-460-06	2840-01-162-6962	VANE ASSEMBLY,EXIT	1	OH
2-141-466-06	2840-01-162-6962	VANE ASSEMBLY,EXIT	2	OH
216-040-833-001			1	NS
218WB	3110-00-554-3213	BEARING,BALL,ANNULAR	4	NS
21C7267P01	4920-01-166-9078		5	NS
22-012-19-40-28	3120-00-840-2730	BUSHING,SLEEVE	8	NS
2222-IF2-A			5	AR
2228J	2935-00-058-1129	NOZZLE,TURBINE,MACH	3	NS
2281-103			1	AR
2-300-908-01	2915-01-113-8523	FLOW DIVIDER,FUEL	2	NS
23030962 COATED	2840-01-212-1279	SHAFT,TURBINE,NONAIRCRAFT GAS TURBINE ENG	13	NS
23030962 COATED	2840-01-212-1279	SHAFT,TURBINE,NONAIRCRAFT GAS TURBINE ENG	39	NS
23030962 COATED	2840-01-212-1279	SHAFT,TURBINE,NONAIRCRAFT GAS TURBINE ENG	20	NS
23030962 COATED	2840-01-212-1279	SHAFT,TURBINE,NONAIRCRAFT GAS TURBINE ENG	68	NS
23030963 COATED	2840-01-212-1279	SHAFT,TURBINE,NONAIRCRAFT GAS TURBINE ENG	27	NS
235-1125	6115-00-321-4648	FITTING,TOWBAR END	1	SV
235M-1N4A	6105-00-148-3602	MOTOR-TACHOMETER GENERATOR	1	NS
240-070-907-1			7	AR
24-164	5340-00-989-7849	CAP,PROTECTIVE,DUST AND MOISTURE SEAL	1	AR
24630-0028	6130-00-084-9052	POWER SUPPLY	1	AR
2524089-2			1	NS
254-001-340-1			1	NS
26001-7023			2	NS
264-010-781-009			8	NS
264-012-116-1			56	NS
266532-1	1650-01-331-6673	FILTER BODY,FLUID	1	NS
2745-013	5935-01-081-0184	ADAPTER,CONNECTOR	41	SV
27707-1	6685-00-766-7936	THERMOCOUPLE,IMMERSION	7	NS
286-070-335-1			2	NS
28B285-43B	6115-01-146-1617		1	NS
295-075-303-1			1	NS
2980-2-254	3110-00-624-3503	CONE AND ROLLERS,TAPERED ROLLER BEARING	6	NS
29C25	5930-00-652-9141	SWITCH,ROTARY	23	NS
2C27-1 FAA CERTS	2915-21-887-5246		2	RP
2H55R6			3	NS
2x48 2A70			3	NS
30-0060-5	6220-00-570-7254	LIGHT,NAVIGATIONAL,AIRCRAFT	1	NS
30010-000	6115-00-725-1790	GENERATOR,DIRECT CURRENT	1	SV
30-056-10W	4730-01-302-8015	CLAMP,PIPE,ANCHOR AND REINFORCEMENT	1	NS
30-1573-2	6220-01-159-8031	LIGHT,NAVIGATIONAL,AIRCRAFT	46	NS
3015871A			1	NS
30300-1282	5977-00-143-6774	BRUSH,ELECTRICAL CONTACT	4	NS
3031M36P02	2915-00-126-5730	NOZZLE,FUEL INJECTION	1	NS
3031M36P02	2915-00-126-5730	NOZZLE,FUEL INJECTION	2	NS
30B24-1-A	6115-00-609-8001	GENERATOR,DIRECT CURRENT	1	NS
30B37-37A	6115-00-942-2094	GENERATOR,DIRECT CURRENT	1	AR
314013.00-5			6	NS

3-160-261-04			4	NS
32081-2	4730-00-007-2233	PLUG,QUICK DISCONNECT	1	NS
32E01-2-A			1	SV
35-62315-3006-4	4320-01-118-9360	PORT PLATE,PUMP	1	NS
364-83021-7	5365-01-142-6428	SHIM	4	NS
369A135			1	NS
369A4025	1730-00-917-3826	COVER,AIRCRAFT GROUND SERVICING	12	SV
369D21613M			2	SV
375525-16	4730-00-991-8552	COUPLING HALF,QUICK DISCONNECT	1	NS
375525-16	4730-00-991-8552	COUPLING HALF,QUICK DISCONNECT	2	NS
383030-01412			1	AR
383030-02412			2	AR
384304-006			2	NS
3886006-2	3010-01-169-1426	DISK,CLUTCH	1	NS
391019-001	6680-00-133-7911	TRANSMITTER,LIQUID QUANTITY	2	NS
393008-074			1	NS
396D26571-47			2	AR
40 001-126-101	1680-01-185-8900	ELBOW ASSY,PILOTS C	1	SV
400466-1			1	NS
40-221A			1	SV
4023403-0501	5895-00-063-9498	MOUNT,TRANSPONDER	1	AR
4023616-0501	5895-00-848-8693	CASE SUBASSEMBLY,RE	1	AR
404IT33G01			5	AR
406-001-305-101	1680-01-185-3059	PIVOT ASSY,PILOTS	3	NS
406-001-355-101	1680-01-236-9821	BOOT ASSEMBLY	5	NS
406-010-123-101			59	NS
406-010-413-113	3040-01-186-4440	CONNECTING LINK,RIGID	1	SV
406-030-102-120	1560-01-292-7867	PLATE,STRUCTURAL,AIRCRAFT	1	SV
406-030-158-103	1615-01-192-4911	BOOT ASSY,SEAL,TRAN	1	NS
406-040-072-105	1615-01-273-7395	SHAFT ASSY,HYDRAULI	3	NS
406-040-091-101	1615-01-184-1752	PLATE,LOCK	1	NS
406-040-318-105	1615-01-184-6134	LINK,HANGER,BEARIN	5	NS
406-052-017-101			13	AR
406-202-106-101			233	NS
406-360-501-101	2935-01-186-7120	COOLER,LUBRICATING OIL,ENGINE	3	NS
41000265C			1	NS
41000970-001			1	NS
41000970-001			1	NS
410236H19	5330-00-425-0261		3	NS
4118-16A	5340-00-031-3115	CLAMP,LOOP	27	NS
413368501-02			1	AR
4220-2	5315-00-198-5966	PIN,TAPERED,PLAIN	1	AR
42550-3	4810-01-022-3699	VALVE,HYDRAULIC,PRE	6	NS
42595-3	4820-00-911-3209	BODY,VALVE	2	NS
430-016-601-3			1	AR
43330-1128			1	AR
43338B			1	NS
442030-1	3120-01-239-5139		4	NS
45-0128-3	6220-01-011-9981	LIGHT,LANDING,AIRCRAFT	1	SV
4596 (DH-58A)	6240-00-577-8450	LAMP,INCANDESCENT	2	NS
47-140-252-3	3120-00-269-4453	BEARING,PLAIN,ROD END	6	NS
475C-81NW	4820-00-088-9751	COCK,POPPET DRAIN	1	NS
47-641-057-G			2	AR
47-641-101-1	5340-00-503-1896	BOOT,DUST AND MOISTURE SEAL	1	NS
47-661-029-007			1	NS
494H832-08	5342-00-131-7243	INSERT	5	NS
49550-0001			1	AR
4RB30802077C			1	NS
4T-13621	3110-01-051-1016	CONE AND ROLLERS,TAPERED ROLLER BEARING	8	NS
501066-1	1720-00-315-9827	REMOTE INDICATOR	1	NS
5035T88P01	2840-01-087-4136	NOZZLE,LUBRICATION	2	AR
50C6777	3990-00-360-0248	BINDER,LOAD	34	NS
51565-00012			1	NS
51610-03308-00	3110-00-672-8763		5	NS
522-2929-000	6310-00-719-7219	INVERTER,POWER,STATIC	3	OH
522-2993-00			1	AR

530772-124G-20N			8	NS
531059A			4	NS
535250-6	5306-00-756-9245	BOLT,EXTERNALLY RELIEVED BODY	6	NS
53DH410512-19	1650-01-280-0640	CABLE ASSEMBLY,SPECIAL PURPOSE,ELECTRICAL	1	NS
540-001-029-1	1680-00-919-2369	GRADIENT ASSEMBLY,F	2	NS
540-001-904-001			1	AR
540-001-904-005	3040-00-918-9938	BELL CRANK	1	RP
540-011-119-19	1615-00-936-2371	BOLT ASSEMBLY,ROTOR BLADE	13	SV
540-011-119-19	1615-00-936-2371	BOLT ASSEMBLY,ROTOR BLADE	12	NS
540-011-129-1	1615-00-867-1139	BARREL,PITCH LINK,MAIN ROTOR	2	NS
540-011-304-1	1615-00-847-7498		2	NS
540-011-309-1	3040-00-866-6064	CONNECTING LINK,RIGID	5	NS
540-011-384-3	1615-00-054-8568	COLLET SET,ROTOR	1	NS
540-040-011-1	1680-00-872-7841	PLATE,MAST BEARING	1	NS
540264-2-1	1680-00-990-3163	ACTUATOR,ELECTRO-MECHANICAL,LINEAR	1	SV
542-4882-003	6220-00-445-4050	PANEL,INDICATING,LIGHT TRANSMITTING	4	NS
544-7905-002	5355-00-043-0302	KNOB	4	NS
545-5858-000	5821-00-845-8985	POWER SUPPLY	1	SV
5469087G5	6685-00-963-1115	THERMOCOUPLE AND HA	3	NS
55-1650-302	1650-00-929-8507	CYLINDER ASSEMBLY,ACTUATING,LINEAR	1	RP
560T32			1	NS
560T32-2	6610-00-139-9757	COMPUTER,AIR DATA	1	AR
563-040-408-003	3110-00-133-6657	BEARING,BALL,DUPLEX	9	NS
574-074-300-5			1	NS
578893-1			35	NS
59100W0-2	3110-00-135-0563	BEARING,BALL,ANNULAR	1	NS
5934P-3			1	OH
60-0027-5			4	NS
6004-7-CD-00553-1D124N			3	NS
6041H189	5945-00-588-8555	RELAY,ELECTROMAGNETIC	1	NS
6041H202A	5945-00-920-7394	RELAY,ELECTROMAGNETIC	1	NS
6041H205A	5945-00-232-5773	RELAY,ELECTROMAGNETIC	4	NS
6041H215	5945-00-660-9315	RELAY,ELECTROMAGNETIC	3	NS
6041H215	5945-00-189-6391	RELAY,ELECTROMAGNETIC	1	NS
6098025-400			4	AR
6240-673447			1	AR
6300-B3A-14A4			1	NS
6340-UH1-017-3	6340-00-169-1598	BOX,WARNING CONTROL	1	AR
6340-VH1-0091			2	NS
63SD/M170 ?	6230-00-892-5192	LIGHT,MARKER,DISTRESS	340	NS
65-0195-1	6220-00-997-6462	LIGHT,INDICATOR	95	NS
6632A0205H	3110-00-791-8116	BEARING,BALL,ANNULAR	25	NS
682-140-088-01	2840-00-983-0525	LOCKWIRE,SECOND TUR	41	NS
6843356-2	3130-00-834-6580	LINER,BEARING HOUSING	9	NS
68A800600-1061	1680-01-003-3765	PANEL,INDICATING,LIGHT TRANSMITTING	14	NS
697218-3	4820-00-484-9024	VALVE,OIL TANK	2	NS
70-004A16F7Z2	4720-01-490-9994	HOSE,AIR DUCT	44	NS
70-004A16F7Z2	4720-01-490-9994	HOSE,AIR DUCT	86	NS
70-010H000T060	4720-01-491-0348	HOSE ASSEMBLY,NONMETALLIC	1	SV
70-010H000T070			1	SV
70-010H000V174	4720-00-163-4634	HOSE ASSEMBLY,NONMETALLIC	10	NS
70072-15001-012			4	NS
70361-03009-045			1	NS
70361-08006-102	3040-01-302-6646	SHAFT,SHOULDERED	1	NS
70400-01405-104	1680-01-095-7301	GRIP ASSEMBLY,COPIIL	1	NS
70400-02260-121	1680-01-285-0344	ACTUATOR,ELECTRO-MECHANICAL,ROTARY	1	RP
70410-02-334-044	6615-01-158-5747	LINK ASSEMBLY	3	NS
70652-02950-105	4320-01-154-1339	PUMPING UNIT,HYDRAULIC,HAND DRIVEN	1	AR
7124MR972P4			20	NS
71-3115014021	1560-01-155-6038	DOOR,ACCESS,AIRCRAFT	20	NS
71-3115014021	1560-01-155-6038	DOOR,ACCESS,AIRCRAFT	7	NS
718973-2	2915-00-816-0884	HOUSING,FUEL CONTROL	1	NS
7-211412050-3	1615-01-163-4522	FITTING,STATIC DISC	2	NS
7-211661029	2929-01-178-0063	SWITCH,LOCK,IGNITION	3	NS
7-311150110-21	1560-01-155-6038	DOOR,ACCESS,AIRCRAFT	24	NS
7-311517003	1560-01-719-085	SEAL,PLAIN ENCASED	28	NS

7-311517003	1560-01-719-085	SEAL,PLAIN ENCASED	32	NS
7570377L22	2915-00-980-7929		1	NS
75V47-1	5930-00-997-2557	SWITCH,PRESSURE	2	NS
760-32-2-10	5340-00-523-1278	STRAP,RETAINING	5	NS
762-1798-001			1	AR
76575-4	5930-00-030-3688	SWITCH,PRESSURE	4	NS
775-4276-001	5996-00-074-3984	AMPLIFIER,ELECTRONIC CONTROL	1	NS
798200-64-2			5	NS
80-0128-21	6220-01-091-8460	LIGHT ASSEMBLY,INDICATOR	1	NS
80-0128-21	6220-01-091-8460	LIGHT ASSEMBLY,INDICATOR	3	NS
88700-1	1650-00-435-4785	MODULAR UNIT,HYDRAU	1	SV
89751 C-084	2915-01-162-9543	FUEL CONTROL,MAIN,TURBINE ENGINE	1	NS
89751 JR-007	2915-01-162-9543	FUEL CONTROL,MAIN,TURBINE ENGINE	1	NS
8DJ67FBC			2	RP
8DJ67FBC			1	RP
8DJ67FBC-1	6680-00-907-8380	INDICATOR,ELECTRICAL TACHOMETER	1	OH
8DJ96LAF1	6620-00-852-5353	INDICATOR,RATE OF FLOW	1	SV
9000-5	1650-01-005-3906	TUBE ASSY,ANTI-ICIN	9	NS
90-140-252-3			4	NS
905D977-4	6110-00-852-0683	REGULATOR,VOLTAGE	1	OH
9101PP	3110-00-152-7327	BEARING,BALL,ANNULAR	9	NS
91357-1	2805-00-753-8628	TAPPET,ENGINE POPPET VALVE	1	NS
9318UP1	3110-01-095-7680	BEARING,BALL,ANNULAR	9	NS
970500-1	5962-00-224-7004	MICROCIRCUIT,LINEAR	8	NS
99-3896M			1	NS
A121304	1615-00-255-2896	MAST,ROTOR,HELICOPTER	1	SV
A218-100646-01	5930-00-522-6866	SWITCH,TOGGLE	1	NS
A24081-1	2995-00-992-9399	BLOWER,AIR INLET SE	1	NS
A-261			26	NS
A3 1/2T14			50	NS
A3 1/2T27	5325-00-281-5070	STUD,TURNLOCK FASTENER	50	NS
A301-1	5831-00-895-4175	CONTROL,INTERCOMMUNICATION SET	2	RP
A348-1-7			19	NS
A35-MA	6610-01-491-4840	ALTIMETER,PRESSURE	1	NS
A4861-1	6210-01-278-5803	RETAINER,LENS	2	NS
A51S62460-1	1730-00-385-2839	RIG PIN SET,CANOPY	1	NS
A5-399			1	AR
A5T26	5325-00-897-6757	STUD,TURNLOCK FASTENER	10	NS
A6075P-1			1	NS
A671F-2	1650-01-116-2945	FILTER ELEMENT,FLUID	1	NS
A792DB	5945-00-759-4568	CONTACTOR	1	NS
AC05A 33428106			1	NS
AC-102-5	5330-00-182-3678	GASKET	2	NS
AC-102-5	5330-00-182-3678	GASKET	1	NS
AC-102-6			2	NS
AC2031F 120PZ			1	NS
ACA388F90			2	NS
AD07B			1	NS
AE366-0060-E-0170			1	NS
AE83206R	4930-01-194-2625	NOZZLE,FUEL AND OIL SERVICING	8	AR
AE935325			2	NS
AE93532J	4730-00-076-0561	COUPLING HALF,QUICK DISCONNECT	4	NS
AE96045J			2	NS
AH050	6530-00-208-6549	CUSHION,WHEELCHAIR SEAT		NS
AL1018-11-00	1680-00-872-1238	COVER,AIRCRAFT SEAT	1	NS
AN/ARC-115	5821-00-431-9824	RADIO SET	1	AR
AN0536-1C/10133			2	AR
AN104906	5306-00-881-8735	BOLT,MACHINE	53	NS
AN174H12	5306-00-145-7659	BOLT,CLOSE TOLERANCE	5	NS
AN175H11A	5306-00-680-6306	BOLT,CLOSE TOLERANCE	1	NS
AN24-9	5306-00-156-2693	BOLT,CLEVIS	32	NS
AN3025-1	5945-01-112-6313	RELAY,ELECTROMAGNETIC	1	SV
AN3025-300	2925-00-555-5349		3	NS
AN3106A-36-2P			4	NS
AN31-55-50-25			1	NS
AN3177-9	6220-00-283-9334	LIGHT,NAVIGATIONAL,AIRCRAFT	6	NS

AN364-624	5310-00-275-2015	NUT,SELF-LOCKING,HEXAGON	52	NS
AN3H24A	5306-00-182-2013	BOLT,MACHINE	25	NS
AN4-33A	5306-00-151-1405	BOLT,MACHINE	25	NS
AN44-10	5306-00-206-3872	BOLT,EYE	23	NS
AN4422A			25	NS
AN4-7A	5306-00-515-8064	BOLT,MACHINE	132	NS
AN4H-14A	5306-00-182-1962	BOLT,MACHINE	14	NS
AN4H3A	5306-00-182-2014	BOLT,MACHINE	2	NS
AN4H5A	5306-00-182-2016	BOLT,MACHINE	2	NS
AN4H6A	5306-00-182-2017	BOLT,MACHINE	96	NS
AN503-8-12	5305-00-145-7012	SCREW,MACHINE	41	NS
AN525-10R16	5305-00-180-3326	SCREW,MACHINE	6	NS
AN5813-1	6610-00-526-7849	PITOT TUBE	1	NS
AN5DDH7A	5306-00-131-2645	BOLT,MACHINE	12	NS
AN6-16A	5306-00-208-3639	BOLT,MACHINE	50	NS
AN6227-19			13	NS
AN6-24	5306-00-167-3690	BOLT,MACHINE	650	NS
AN6244-4	5330-00-186-4937	GASKET	25	NS
AN6-35A	5306-00-180-0313	BOLT,MACHINE	100	NS
AN815-10	4730-00-187-0488	NIPPLE,BOSS	7	NS
AN815-4D	4730-00-925-4752	NIPPLE,BOSS	1	NE
AN815-6	4730-00-187-0486	NIPPLE,BOSS	8	NS
AN815-6	4730-00-187-0486	NIPPLE,BOSS	4	NS
AN894D4			2	NS
AN919-12D	4730-00-187-3585	REDUCER,BOSS	2	SV
AN919-6	4730-00-187-3600	REDUCER,BOSS	2	NS
AN938-4	4730-00-278-2780	TEE,BOSS	11	NS
AN938D8	4730-00-277-5055	TEE,BOSS	6	NS
AN960-10L	5310-00-167-0834	WASHER,FLAT	4	NS
AN960-1OL			12	NS
AN960-416L	5310-00-167-0835	WASHER,FLAT	4	NS
AN960J0516			8	NS
AN968PD12162			17	NS
AN970-3	5310-00-167-0765	WASHER,FLAT	550	NS
AN970-4	5310-00-167-0766	WASHER,FLAT	850	NS
AN975-3	5310-00-167-0685	WASHER,RECESSED	275	NS
ANG-24	5306-00-167-3690	BOLT,MACHINE	600	NS
ANS25010R10			50	NS
ANS2S-832127			679	NS
AR133	1680-00-411-0041	HANDLE,DOOR	1	AR
AR5060			1	NS
AS1096			3	NS
AS-1703/AR	5629-00-082-3991	ANTENNA	1	AR
ATW10-4D ?	3120-00-110-8541	BEARING,PLAIN,SELF-ALIGNING	1	NS
AV16B1296D	2915-00-778-2298	VALVE,GATE,AIRCRAFT	3	RP
AW 31/2T20	5325-00-639-4201	STUD,TURNLOCK FASTENER	19	NS
B188	3110-00-120-3089	BEARING,ROLLER,NEEDLE	7	NS
B19056	2910-00-803-9525	FILTER ELEMENT,FLUID	3	NS
B541DD	3110-00-293-8584	BEARING,BALL,AIRFRAME	1	NS
B7584-2	1650-00-924-7714	FITTING AND FILTER	2	NS
B850-4	6610-01-042-2484		2	NS
BACB30SX20 45	5306-01-309-6512	BOLT,SHEAR	40	NS
BACB30SX240	5306-01-309-6512	BOLT,SHEAR	12	NS
BACR11Y3C	5325-00-638-8088	RECEPTACLE,TURNLOCK FASTENER	10	NS
BACR150N3AD16			3	NS
BACR150N3AD16			1	NS
BACR150N4AD-16			1	NS
BD6-3	5935-00-686-0447	CONNECTOR,PLUG,ELECTRICAL	3	NS
BEP761A	6230-00-892-5192	LIGHT,MARKER,DISTRESS	1	NS
BF13305	4210-00-933-2929	BRACKET,FIRE EXTINGUISHER	1	NS
BG3	5330-01-363-1497	GASKET	1	OH
BH-1030-24-100-CS	6130-00-225-3465	INVERTER,POWER,STATIC	1	OH
BH11730			2	NS
BL-13800-2	1680-00-538-8665	WINCH,AIRCRAFT MOUNTED	1	NS
BN29320	2520-00-894-9549	BEARING,ROLLER,CYLINDRICAL	8	NS
BUNCH OF USED FITTINGS				NS

C050N-L1			1	NS
C-10414P1ARC	5831-01-157-5102	CONTROL,INTERCOMMUNICATION SET	1	NS
C-108005	2840-00-054-3591		32	NS
C-108005	2840-00-054-3591		1	NS
C-108027	2840-00-054-3592	SEAL,PLAIN ENCASED	1	NS
C1160	5841-00-303-2627	CONTROL ROLL AND PI	1	NS
C1514			1	NS
C15141A			1	SV
C-2275/ARN	5895-00-688-6030	CONTROL,RECEIVER	1	AR
C-3436A/ARN-30E			1	AR
C-376016			163	NS
C-3835/ARC-54	5821-00-082-3599	CONTROL,RADIO SET	3	AR
C-39401ARL-94			2	NS
C515920-16R			1	NS
C612201R	5930-00-825-3407	SWITCH,PRESSURE	1	NS
C-6287A/ARC-51BX	5821-00-237-6019	CONTROL,RADIO SET	1	AR
C-6899/ARN-83	5826-00-985-9174	CONTROL,DIRECTION FINDER	1	SV
C-6899/ARN-83	5826-00-985-9174	CONTROL,DIRECTION FINDER	1	AR
C-6A	5961-00-869-4857	SEMICONDUCTOR DEVICE,THYRISTOR	1	AR
C-6A	5961-00-869-4857	SEMICONDUCTOR DEVICE,THYRISTOR	1	SV
C7088/ARC131	5821-00-937-9614	CONTROL,RADIO SET	1	AR
C-7088/ARC-131	5821-00-937-9614	CONTROL,RADIO SET	1	AR
C-7088/ARC-131	5821-00-937-9614	CONTROL,RADIO SET	1	AR
C-8157/ARC	5821-00-926-7230	CONTROL,INDICATOR	1	AR
C-8157/ARC	5821-00-926-7230	CONTROL,INDICATOR	6	AR
C-8157/ARC	5821-00-926-7230	CONTROL,INDICATOR	1	AR
CB2100T4AM	6605-00-435-3039		2	NS
CE-43592	2915-00-671-7944		2	NS
CE-77970			3	NS
CE-80497	5360-00-867-1689		3	NS
CE-83307	2915-00-020-6549	PARTS KIT,PUMP,OVER	1	NS
CE85636	2915-00-828-3369	HOUSING,SECONDARY G	1	NS
CI122			1	AR
CM-75168	3020-00-088-8872	GEAR SET,SPUR,MATCHED	91	NS
CN-998B/ASN-43	6615-00-167-9757	GYROSCOPE,DISPLACEMENT	1	AR
CPW3003476-A			1	NS
CPW3007194-A			1	NS
CSV1152-12AB CERTS BY	6110-01-065-3716	REGULATOR,VOLTAGE	1	RP
CTL-201A			3	NS
CV-1Z75/ARN			1	AR
CV-265A/ARN-30A	5895-00-519-5602	CONVERTER,SIGNAL DATA	1	AR
CV-265A/ARN-30A	5895-00-519-5602	CONVERTER,SIGNAL DATA	1	AR
D7200151A	4030-00-709-6091	COUPLING,WIRE ROPE,QUICK DISCONNECT	1	NS
DAA501-68A0005341	1560-00-886-2153	FAIRING,AIRCRAFT	8	NS
DAA509-90-C-1107	1560-00-701-9923	WINDOW PANEL,AIRCRAFT	13	NS
DSL147			1	AR
DYLM43301-24	3010-00-070-6123	GEARCASE-MOTOR	1	AR
E-31400	5945-00-558-3915		1	NS
EV211343N			3	NS
F17A			1	AR
F32827			5	NS
F-74356	5930-00-842-6470	SWITCH,LIMIT	1	AR
F-9457	1615-00-181-5552	CAP AND FILLER ASSY	4	NS
FC-1577	5915-00-081-3929	FILTER,RADIO FREQUENCY INTERFERENCE	2	NS
G203	6140-00-538-6058	BATTERY,STORAGE	1	NS
G354			5	NS
G51P A	5325-00-220-5576	GROMMET,NONMETALLIC	1	NS
G52-1161-226-H5	3020-00-884-5980	GEAR,ANTIBACKLASH,SPUR	5	NS
G-6381	6140-01-128-0415	BATTERY,STORAGE	1	NS
G8385-1	6220-00-075-1989	LIGHT,LANDING,AIRCRAFT	1	AR
G8385-1	6220-00-075-1989	LIGHT,LANDING,AIRCRAFT	2	NS
G9125-1	6220-00-583-3193	LIGHT,RECOGNITION,AIRCRAFT	1	NS
G98	4820-00-142-2881	DISK,VALVE	2	NS
GEV/7-A			1	AR
GG202B1			1	AR
H-143/AIC	5965-00-615-0104	EARPHONE ELEMENT	1	AR

H158A-5	4920-00-253-1343	COMPUTER-RECORDER	1	NS
H60-480-01			1	NS
H6055063A123			6	NS
HAP-0001-01			6	AR
ID-1003/ARC	6625-00-978-7867	INDICATOR,STANDING WAVE RATIO	10	AR
IND-A5-UH1	6610-00-781-8531	INDICATOR,ATTITUDE	2	NS
IND-A5-UH1	6610-00-781-8531	INDICATOR,ATTITUDE	2	OH
J252	4730-00-996-8258	CLAMP,HOSE	125	NS
JB-15			1	NS
KP8A	3110-00-554-0029	BEARING,BALL,AIRFRAME	2	AR
KPN066-4003-00			1	AR
KRJ26-SB-023	3120-01-184-0359	BEARING,SLEEVE	359	NS
KSP9046-5	1650-01-028-0451	SHIELD,CYLINDER	2	NS
KT-76A			1	NS
LA17BT	5831-00-435-2221	AMPLIFIER,AUDIO FREQUENCY	1	SV
LA-71-11			1	AR
LP-1002 P 1801	5930-00-823-0959	SWITCH ASSEMBLY	6	NS
LTCT21024-03	6685-00-183-0724	TRANSMITTER,PRESSURE	1	AR
LTCT511	4920-00-491-0840	INSTALLATION TOOL,S	1	NS
M1400-01-01	6610-00-758-2385	INDICATOR,ATTITUDE	1	NS
M1L-R-11			5	NS
M524393-4			19	NS
M8324812-904	5330-00-166-5994	O-RING	1	NS
M83796	4720-00-257-0420	HOSE ASSEMBLY,NONMETALLIC	29	NS
MA 44 72			2	NS
MDE32256-3	1730-00-724-7897	YOKE,HOISTING SLING	3	NS
MHMS919404			4	NS
MI-585149 PRIMUS 20			1	AR
MI-591003-2			1	SV
MIL-H-13444	4720-01-279-3034	HOSE ASSEMBLY,NONMETALLIC	1	NS
ML327	6240-00-155-7836	LAMP,INCANDESCENT	60	NS
MM210VM2	3110-00-727-3032		1	NS
MNS4-02	1650-00-698-6444	VALVE,DIRECTIONAL FLOW	8	OH
MR200EX1	3110-00-179-7399	BEARING,ROLLER,CYLINDRICAL	1	NS
MR211E1			2	NS
MS14144L8	5310-01-057-3109	NUT,SELF-LOCKING,EXTENDED WASHER,HEXAGON	4	SV
MS15001-2	4730-00-172-0001	FITTING,LUBRICATION	9	NS
MS15001-4	4730-00-050-4207	FITTING,LUBRICATION	42	NS
MS165662-198			3	NS
MS172272	5310-00-814-7325	WASHER,KEY	17	NS
MS18029-125-4			1	NS
MS20007			5	NS
MS20009			4	SV
MS20068141	5315-00-781-2002	KEY,MACHINE	12	SV
MS20201KP10A	3110-00-027-4028	BEARING,BALL,AIRFRAME	3	NS
MS20220-4	3020-00-881-2063	PULLEY,GROOVE	2	NS
MS20392-259	5315-00-235-1230	PIN,STRAIGHT,HEADED	3	NS
MS20392-4c53	5315-00-957-2401	PIN,STRAIGHT,HEADED	2	NS
MS20470A4-9	5320-00-803-7118	RIVET,SOLID	1	NS
MS20760			10	NS
MS21045L8	5310-00-857-5562	NUT,SELF-LOCKING,HEXAGON	19	NS
MS21059L08	5310-00-777-5787	NUT,SELF-LOCKING,PLATE	25	NS
MS21059L3	5310-00-777-5791	NUT,SELF-LOCKING,PLATE	69	NS
MS21083N14	5310-00-942-5183	NUT,SELF-LOCKING,HEXAGON	29	NS
MS21122-14	5340-00-256-7342	CLAMP,LOOP	26	NS
MS21122-14	5340-00-256-7342	CLAMP,LOOP	1	AR
MS21122-14	5340-00-256-7342	CLAMP,LOOP	100	NS
MS21122-34			20	NS
MS21122-34			50	NS
MS21122W14			6	NS
MS211532	3110-00-232-3245	BEARING,BALL,ROD END	9	NS
MS21245L14	5310-00-445-5336	NUT,SELF-LOCKING,HEXAGON	1	NS
MS21245L14	5310-00-445-5336	NUT,SELF-LOCKING,HEXAGON	73	NS
MS21251B2L	5340-00-067-9873	TURNBUCKLE BODY	2	NS
MS21254-2LS	5340-00-069-0594	CONNECTOR,ROD END	7	NS
MS21254-2RS	5340-00-069-0595	CONNECTOR,ROD END	2	NS

MS21254-2RS	5340-00-069-0595	CONNECTOR,ROD END	6	NS
MS21902D16	4730-00-289-6091	NIPPLE,BOSS	10	NS
MS21907D12	4730-00-640-1212	ELBOW,TUBE	6	NS
MS21908			3	AR
MS21911D-4	4730-00-640-5111	TEE,TUBE TO BOSS	2	NS
MS21916D6-4	4730-00-640-7201	REDUCER,BOSS	6	NS
MS21919	5935-00-396-3117	CLAMP	3	NS
MS219190G8			88	NS
MS21919D612			96	NS
MS21919WH2	5340-00-579-1531	CLAMP,LOOP	1	NS
MS21919WH3	5340-00-655-4760	CLAMP,LOOP	4	NS
MS21983-1	6125-00-938-6539	MOTOR-GENERATOR	1	SV
MS22034-2	1680-00-592-4878	ADAPTER QUICK DISCONNECT PASSENGER SEAT	1	NS
MS24166-D1	5945-00-686-6877	RELAY,ELECTROMAGNETIC	1	NS
MS2417201			1	NS
MS24392D12	4730-00-684-6914	NIPPLE,TUBE	8	NS
MS24393012			2	NS
MS24693BB275	5305-00-225-6214	SCREW,MACHINE	16	NS
MS24694S55	5305-00-719-5404	SCREW,MACHINE	50	NS
MS25002-1	5930-00-538-5508	SWITCH,ROTARY	3	NS
MS25002-12	5930-00-538-5508	SWITCH,ROTARY	3	NS
MS25010B11A327	6210-00-295-0898	LIGHT,PANEL	39	NS
MS25025-1	6625-00-544-5899	METER,SPECIAL SCALE	1	NS
MS25027-1	6220-00-295-0897	LIGHT,COCKPIT,AIRCRAFT	4	NS
MS25041-3	6210-00-538-8770	LIGHT,INDICATOR	5	NS
MS25083-1AB3	6150-00-617-1578	LEAD,ELECTRICAL	2	NS
MS25083-2BC18	6150-00-916-3979	LEAD,ELECTRICAL	8	NS
MS25089-5AR	5930-00-687-1973	SWITCH,PUSH	1	NS
MS25125E3	5930-00-615-8412	SWITCH,TOGGLE	1	NS
MS25235-311	6240-00-155-7924	LAMP,INCANDESCENT	4	NS
MS25244-25	5925-00-805-2833	CIRCUIT BREAKER	1	NS
MS25244-35	5925-00-686-3299	CIRCUIT BREAKER	1	NS
MS27183-10	5310-00-809-4058	WASHER,FLAT	14	NS
MS27641-10	3110-00-027-4028	BEARING,BALL,AIRFRAME	6	NS
MS27641-3	3110-00-027-8758	BEARING,BALL,AIRFRAME	5	NS
MS27641-6	3110-00-034-5257	BEARING,BALL,AIRFRAME	6	NS
MS27977-29N	5325-00-276-4918	STUD,SNAP FASTENER	100	NS
MS28005-1	6620-00-553-8988	TRANSMITTER,PRESSURE	2	NS
MS28009-1	6685-00-557-0370	INDICATOR,TEMPERATURE,ELECTRICAL RESISTAN	2	NE
MS28010-1	6620-00-514-5334	INDICATOR,PRESSURE	2	NS
MS28010-1	6620-00-514-5334	INDICATOR,PRESSURE	1	AR
MS28010-1	6620-00-514-5334	INDICATOR,PRESSURE	1	NS
MS28034-1	6685-00-373-9004	TRANSMITTER,TEMPERATURE,ELECTRICAL RESIST	3	NS
MS280411B	6610-00-337-9874	INDICATOR,TURN AND SLIP	1	NS
MS28913-5C	3110-00-460-5244	BEARING,ROLLER,AIRFRAME	7	NS
MS28990-4			1	NS
MS29513-033	acush		149	NS
MS29513-226	5331-00-263-5173	O-RING	1	NS
MS29529-12	4820-00-088-9751	COCK,POPPET DRAIN	1	NS
MS29561-238	5331-00-806-4171	O-RING	20	NS
MS30573A	5935-00-028-3613	CLAMP,CABLE,ELECTRICAL CONNECTOR	6	SV
MS3106F-20-235			3	NS
MS3106R36-6P	5935-00-849-7173	CONNECTOR,PLUG,ELECTRICAL	1	NS
MS3126E14-19P	5935-00-988-4350	CONNECTOR,PLUG,ELECTRICAL	3	NS
MS3456W1052L-45			4	NS
MS3456W10SL	5935-00-509-6194	CONNECTOR,PLUG,ELECTRICAL	1	NS
MS35198-238			199	NS
MS35338-44	5310-00-582-5965	WASHER,LOCK	2	NS
MS35803-214/AN6246-19			197	NS
MS8000E210C	4720-00-449-0000	HOSE ASSEMBLY,NONMETALLIC	3	NE
MS8000E320E170			4	NE
MS8000G130A	4720-00-491-4991	HOSE ASSEMBLY,NONMETALLIC	2	NE
MS8000J2206			1	NS
MS87028E123A	4720-01-439-9165	HOSE ASSEMBLY,NONMETALLIC	7	NS
MS87028E123A	4720-01-439-9165	HOSE ASSEMBLY,NONMETALLIC	7	NS
MS87028E46A			2	NS

MS87028G1103			2	NS
MS87028H090A			3	NS
MS87028H175A			10	NS
MS87028K146A			1	NS
MS87028K322E140	4720-98-105-8113		1	NS
MS87028K360C			1	NS
MS9136-01	5330-00-023-7626	GASKET	37	NS
MS9482-12	5310-00-935-8989	WASHER,RECESSED	48	NS
MX-1646/AIC	5935-00-300-3135		1	OH
MX-1646/AIC	5935-00-300-3135		2	AR
MX367037D			1	RP
N80P16018C6	5305-00-688-2342	SCREW,MACHINE	10	NS
NA66205-32D			50	NS
NAS1097AD3-5	5320-00-071-5926	RIVET,SOLID	1	NS
NAS1104-34	5306-00-616-8435	BOLT,SHEAR	18	NS
NAS1149C0463R			400	NS
NAS1149F0963P			600	NS
NAS1149F0963P			50	NS
NAS1149F1490P	5310-01-429-5082	WASHER,FLAT	20	NS
NAS1204-15	5305-00-815-4780	SCREW,CLOSE TOLERANCE	1	NS
NAS1204-15	5305-00-815-4780	SCREW,CLOSE TOLERANCE	9	NS
NAS1304-1211			8	NS
NAS1304-17D			48	NS
NAS1305-64DH	5306-00-944-7540	BOLT,SHEAR	11	NS
NAS130631DH	5306-00-958-9318	BOLT,SHEAR	6	NS
NAS1354DS7S29	5315-00-951-6903	PIN,QUICK RELEASE	11	NS
NAS1374A1ZCA	4720-00-877-6419	HOSE,AIR DUCT	16	NS
NAS1375A125A022			1	SV
NAS147RBM	5306-00-063-9882	BOLT,INTERNAL WRENCHING	6	NS
NAS15985Y	5330-00-762-2891	PACKING WITH RETAINER	3	NS
NAS404P8-90			20	NS
NAS42DD-4-10	5365-00-580-1145	SPACER,SLEEVE	10	NS
NAS42DD-4-6			22	NS
NAS42DD-4-8	5365-00-294-3238	SPACER,SLEEVE	6	NS
NAS43DD6-25	5365-00-142-6499	SPACER,SLEEVE	2	NS
NAS43DDS-25			1	NS
NAS464-4A17	5306-00-550-3504	BOLT,SHEAR	2	NS
NAS464P8-69	5306-00-771-6031	BOLT,SHEAR	5	NS
NAS537B5P036			15	NS
NAS557-16B	5325-00-543-3058	GROMMET,NONMETALLIC	1	NS
NAS5S61C8-18			9	NS
NAS6204-17D	5306-01-143-3989	BOLT,SHEAR	4	NS
NAS6606-34			6	NS
NAS679C3M	5310-00-816-1879	NUT,SELF-LOCKING,SLOTTED,HEXAGON	52	NS
PS-5C			1	AR
PT05A-10-6S	5935-00-852-6522	CONNECTOR,PLUG,ELECTRICAL	9	NS
PT06E-8-2S	5935-00-577-8757	CONNECTOR,PLUG,ELECTRICAL	2	NS
R-1021/ARN-30D	5826-00-752-5730	RECEIVER,RADIO	1	AR
R-1021/ARN-30D	5826-00-752-5730	RECEIVER,RADIO	1	AR
R-1388/ARN-82	5826-00-407-7300	RECEIVER,RADIO	1	AR
R-1388/ARN-82	5826-00-407-7300	RECEIVER,RADIO	1	AR
R-13881ARN87			1	AR
R-1391/ARN-83	5826-00-994-1578	RECEIVER,RADIO	2	RP
R-1838/APR-39(V)	5841-01-031-5890	RECEIVER,RADAR	1	AR
R33A			1	SV
R85CP117-3				AR
RA13006	4730-01-081-4335		2	NS
RB30701-1	1680-01-100-1746	CUSHION,SEAT,AIRCRAFT	1	AR
RD17353	4320-00-065-5504	ROTOR ASSEMBLY,PUMP	32	NS
RD17353	4320-00-065-5504	ROTOR ASSEMBLY,PUMP	32	NS
RD17675-1			15	NS
REM8-34 FC10000 S6	3120-00-902-7926	BEARING,PLAIN,ROD END	75	NS
RG12470	2915-00-921-5660	PUMP,SUBMERGED,AIRCRAFT	7	NS
RG17350	4320-00-977-7488	PUMP,ROTARY	1	OH
RG17670	4320-00-901-6281	PUMP,ROTARY	1	SV
RG510-48			1	AR

RI-011-1	6680-00-857-2397	INDICATOR,SIGHT,LIQUID	1	NS
RN44100-1000			1	AR
RRT-237-L			10	NS
RT-742C/ARC-51BX	5821-00-134-6239	RECEIVER-TRANSMITTER,RADIO	1	AR
RT-823/ARC-131	5821-00-851-1096	RECEIVER-TRANSMITTER,RADIO	1	AR
RWSS-8-1	3120-00-878-4389	BEARING,PLAIN,SELF-ALIGNING	1	AR
S12K58A5			40	NS
S52237	1650-00-213-0660	FILTER ELEMENT,FLUID	12	NS
S52237	1650-00-213-0660	FILTER ELEMENT,FLUID	4	NS
S6137-91102			1	NS
S7LU-3			2	AR
SFR2-6PPXK25	3110-00-819-0571	BEARING,BALL,ANNULAR	82	NS
SGT-223-1	1650-00-725-7746	CYLINDER,ACTUATING,LINEAR	1	NS
SKCP2348-5	1615-01-268-5777	DRIVE SHAFT ASSEMB	4	RP
SP-4220-2	1680-00-967-7639	HOOK ASSEMBLY,CARGO	1	AR
SSCX11194			6	NS
SSR1F3332ZZH			211	NS
STD3053-50	5305-00-831-4082	SCREW,CAP,SOCKET HEAD	11	NS
SWE8100	5120-00-337-9652	MULTIPLIER,TORQUE WRENCH	1	AR
SYLC520	2995-00-828-2492	RESISTOR,FIXED,WIRE WOUND,INDUCTIVE	2	NS
T101360-7	5340-00-878-5748	STRAP,RETAINING	2	NS
T101553	5180-00-176-3701	TOOL SET,PLUNGER AS	15	NS
TD105	5840-00-505-0846	GENERATOR,PULSE	3	SV
TLF816			1	NS
TS-1843A/APX	5895-00-895-4446	MONITOR,TRANSPONDER SET	1	AR
TSO-C53A			1	NS
UN940 PD416			500	NS
W202PP	3110-00-715-0117	BEARING,BALL,ANNULAR	7	NS
W51018-14-00			1	NS
X1595S			50	NS